HITACHI

SERVICE MANUAL



– VT-FX621A –



– VT-FX623A –

TK | No. 4624E

VT-FX621A
VT-FX623A

US MECHANISM

This service manual does not include information on the US Mechanism used in this model. Refer to the following manual for the US Mechanism.

Manuals to be referred VT-FX621A/FX623A.

Name of manual	Manual No.
US Mechanism	4527E

VHS
This video deck is a VHS type video recorder. For proper operation, only the VHS type cassette must be used.

VCR Plus+ w/Cable Channel Changer

SPECIFICATIONS AND PARTS ARE SUBJECT TO CHANGE FOR IMPROVEMENT

VIDEO CASSETTE RECORDER

December 1996 Image & Information Media Systems Division, Tokai

SAFETY PRECAUTIONS

NOTICE: Comply with all cautions and safety related notes located on or inside the cabinet and on the chassis.

1. When replacing a chassis in the instrument, all the protective devices must be put back in place, such as barriers, non-metallic knobs, adjustment and compartment covers/shields, isolation resistors/capacitors, etc.
2. When service is required, observe the original lead-dress. Extra precautions should be taken to assure correct lead dress in the high voltage circuit.
3. Always use the manufacturer's replacement components. Especially critical components as indicated on the circuit diagram should not be replaced by other manufacturers'. Furthermore, where a short-circuit has occurred, replace those components that indicate evidence of overheating.
4. Before returning an instrument to the customer, the service technician must thoroughly test the unit to be certain that it is completely safe to operate without danger of electrical shock, and be sure that no protective device built into the instrument by the manufacturer has become defective or inadvertently defeated during servicing. Therefore, the following checks should be performed for the continued protection of the customer and service technician.

Leakage Current Cold Check

With the AC plug removed from the AC120V, 60Hz source, place a jumper across the two plug prongs. Turn the AC power switch on. Using an insulation tester (DC500V), connect one lead to the jumpered AC plug and touch the other lead to exposed metal parts (antennas, screwheads, metal overlays, control shafts, etc.), particularly any exposed metal part having a return path to the chassis. Exposed metal parts having a return path to the chassis should have a minimum resistor reading of 0.3 Mohm and a maximum resistor reading of 5 Mohm. Any resistor value below or above this range indicates an abnormality which requires corrective action. Exposed metal parts not having a return path to the chassis will indicate an open circuit.

Leakage Current Hot Check

Plug the AC line cord directly into a AC120V, 60Hz outlet (do not use an isolation transformer for this check).

Turn the AC power switch on. Using a "Leakage Current Tester", measure for current from all exposed metal parts of the cabinet (antennas, screwheads, metal overlays, control shaft, etc.), particularly an exposed metal part having a return path to the chassis, to a known ground (earth) (water pipe, conduit, etc.). Any current measured must not exceed 0.5 mA.


LEAKAGE CURRENT TESTER
(READING SHOULD NOT BE ABOVE 0.5 mA)
DEVICE UNDER TEST
TEST ALL EXPOSED METAL SURFACES
2-WIRE CORD
ALSO TEST WITH PLUG REVERSED (USING AC ADAPTER PLUG AS REQUIRED)
GROUND (EARTH)

AC Leakage Test

ANY MEASUREMENTS NOT WITHIN THE LIMITS OUTLINED ABOVE ARE INDICATIVE OF A POTENTIAL SHOCK HAZARD AND MUST BE CORRECTED BEFORE RETURNING THE UNIT TO THE CUSTOMER.

PRODUCT SAFETY NOTICE

Many electrical and mechanical parts have special safety-related characteristics. These are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for a higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in this Service Manual. Electrical components having such features are identified by marking with a ⚠ on the schematics and the parts list in this Service Manual. The use of a substitute replacement component which does not have the same safety characteristics as the HITACHI recommended replacement one, shown in the parts list in this Service Manual, may create shock, fire, or other hazards. Product safety is continuously under review and new instructions are issued from time to time. For the latest information, always consult the current HITACHI Service Manual. A subscription to, or additional copies for, HITACHI Service Manual may be obtained at a nominal charge from HITACHI SALES CORPORATION.

CONTENTS

CHAPTER 1 GENERAL INFORMATION

Specifications 1-1
Comparison with Previous Model 1-2
Comparison of Main Control ICs 1-3
Tips for Servicing 1-4
Trouble Display Function 1-4
How to Remove the Cassette when a Malfunction Has Occurred in the Mechanism ... 1-5
Instructions on Use and Description of New Functions 1-6
SERVICE MANUAL ABBREVIATION LIST 1-8
LEADLESS (CHIP) COMPONENT IDENTIFICATION 1-10

CHAPTER 2 DISASSEMBLY

DISASSEMBLY
1. Before Starting Disassembly 2-1
2. Disassembly Method 2-1
Parts Hierarchy Chart 2-1
Disassembly Procedure Diagrams 2-2
2-1. Top cover, front panel, rear panel and US-FL mechanism 2-2
2-2. Cassette door and buttons 2-2
2-3. LED board (For VT-FX623A) 2-3
2-4. Front frame and LCD board 2-3
2-5. US mechanism/MAS board assembly 2-3
2-6. Separation of MAS board from US mechanism 2-4
2-7. Procedure to remove only the US mechanism 2-4
3. Cautions When Reinstalling the US Mechanism 2-5

CHAPTER 3 ELECTRIC CIRCUIT ADJUSTMENT

Servicing Position 3-1
1. Servicing position during electrical adjustment 3-1
2. Servicing positions when repairing and checking circuits 3-1
3. Be careful of electric shocks 3-1
Electrical Circuit Adjustment 3-2
1. Test equipment/jigs necessary for adjustment 3-2
2. Cautions on adjustment 3-2
3. Tips for adjustment 3-2
4. Connections of test equipment 3-2
Test Points and Adjustment Points 3-3
5. Servo Circuit Adjustments 3-4
5-1. Switching point adjustment 3-4
5-2. X-value adjustment 3-4
5-3. Vertical jitter adjustment 3-5
5-4. Forward slow tracking preset adjustment 3-5
5-5. Reverse slow tracking preset adjustment 3-5
6. Audio/MTS Circuit Adjustments 3-6
6-1. Hi-Fi audio playback level check 3-6
6-2. MTS input level adjustment 3-6
List of Data in EEPROMs and Initial Settings . 3-7
List of Hidden Commands 3-7
Initial Settings of IC903 (EEPROM) 3-8
Caution When Replacing IC903 (EEPROM) 3-8

CHAPTER 4 EXPLODED VIEWS

EXPLODED VIEWS
1. CABINET SECTION 4-1
2. US-MECHANISM (TOP VIEW) SECTION 4-2
3. US-MECHANISM (BOTTOM VIEW) SECTION 4-3
4. CASSETTE LOADING MECHANISM SECTION 4-4

CHAPTER 5 REPLACEMENT PARTS LIST

REPLACEMENT PARTS LIST
1. MECHANICAL PARTS LIST 5-1
2. ELECTRICAL PARTS LIST 5-2

CHAPTER 6 SCHEMATIC AND CIRCUIT BOARD DIAGRAMS

SCHEMATIC AND CIRCUIT BOARD DIAGRAMS

INTERNAL WIRING DIAGRAM 6-1

	SCHEMATIC DIAGRAM	CIRCUIT BOARD DIAGRAM
LCD DISPLAY (LCD)	6-2 /	6-18
CYLINDER MOTOR DRIVE	6-4 /	-
CAPSTAN MOTOR	6-4 /	-
MECHANISM SENSOR (MAS)	6-5 /	6-20
MAIN CONTROL (MAS)	6-6 /	6-20
LED (LED)	6-7 /	6-18
MTS/JACK (MAS)	6-8 /	6-20
PRE AMP/FM AUDIO (MAS)	6-10 /	6-20
LUMA/CHROMA, LINEAR AUDIO (MAS) ...	6-14 /	6-20
SWITCHING REGULATOR (MAS)	6-16 /	6-20
SERVO WAVEFORMS		6-5
LUMA/CHROMA WAVEFORM		6-13

CHAPTER 7 TROUBLE DISPLAY, BLOCK DIAGRAMS AND MICROPROCESSOR PIN FUNCTION TABLES

Troubleshooting According to Malfunction Display 7-2
2. BLOCK DIAGRAM 7-8
SYSTEM CONTROL 7-8
SERVO 7-10
AUDIO 7-12
VIDEO 7-14
POWER SUPPLY 7-16
3. MICROPROCESSOR PIN FUNCTION TABLES 7-18
4. Troubleshooting the Switching Regulator . 7-22

CHAPTER 1 GENERAL INFORMATION

Specifications

Format:	VHS
Video Signal System:	NTSC color EIA standard
Record/Playback System:	Video: 4 Heads
	Audio: VHS Hi-Fi stereo record/playback system
Tape Speed:	33.35mm/sec(SP), 16.67mm/sec(LP)(playback only), 11.12mm/sec(EP)
RF Input:	UHF/VHF75 ohm
Tuner:	USA: 181 channel tuning ability* (125 cable channels)
	Canada: 178 channel tuning ability* (122 cable channels)
Type:	Auto programming frequency synthesis
Power Input:	AC120V 60Hz
Power Consumption:	20W norminal (FX621A)
	22W norminal (FX623A)
Cabinet Size:	14-15/16″ (W)×3-11/16″ (H)×10-11/16″ (D)
	38.0cm(W)×9.3cm(H)×27.1cm(D)
Weight:	7.7lbs. (3.5kg)
Storage Temperature:	-4° F to 131° F
Operating Temperature:	41° F to 104° F
Accessories:	1 coaxial cable
	1 remote control unit
	2AA batteries

Design and specifications subject to change without notice.

Comparison with Previous Model

Item		VT-FX621A/FX623A	VT-FX610A/FX611A/FX613A
Video	Video recording/playback system	VHS	VHS
	Y/C separation	Comb filter	Comb filter
	YNR (noise reduction)	○	○
	CNR (noise reduction)	×	×
	Picture quality function	×	×
	Color edge clean circuit	×	×
	Vertical chroma correction	×	×
	New sync circuit	○ (PB)	○ (PB)
	Picture control	×	×
	S-VHS quasi playback function	×	×
Jacks	Video/audio inputs (rear)	1／2	1／2
	Video/audio inputs (front)	1／2 (FX623A)	1／2
	Video/audio outputs (rear)	1／2	1／2
	Video/audio outputs (front)	×	×
Prog.	VCR Plus + programming	○	○
	Number of timer programs	8 programs/1 year	8 programs/1 year
	Auto recording speed	×	×
Remote	Model	VT-RM621A (FX621A) VT-RM623A (FX623A)	VT-RM611A (FX610A/FX611A) VT-RM613A (FX613A)
	Remote jog/shuttle	×／×	×／×／○(FX613A)
	VCR Plus + code guide channel memory	×	×
Miscellaneous	Auto clock setting	×／○(FX623A)	×／○／○(FX611A/FX613A)
	Jog/Shuttle dial on the VCR	×／×	×／×／○(FX613A)
	Cable box control	×／○(FX623A)	×／×／○(FX613A)
	Tape navigation	×	×
	Closed caption	×	×
	Self-diagnosis	○ (6 modes)	○ (6 modes)
	No. of channels	181	181
	Backup time	1 hour	1 hour
	Front display (display tube)	LCD	LCD
	Synchro input jack	×	×
Mechanism	Basic chassis type	US	US
	Fast forward/rewind time (with T-120)	about 120 seconds	about 120 seconds
	Configuration of heads	DA4 heads + HiFi SP video : 2 (48/56μm) EP video : 2 (19/19μm) Audio : 2 (28/28μm)	DA4 heads + HiFi SP video : 2 (48/56μm) EP video : 2 (19/19μm) Audio : 2 (28/28μm)
	Material of heads	SP video : Ferrite EP video : Ferrite Audio : Ferrite	SP video : Ferrite EP video : Ferrite Audio : Ferrite
	Head cleaning roller	×／○ (FX623A)	○

Comparison of Main Control ICs

Item	Function	VT-FX621A/FX623A	VT-FX610A/FX611A/FX613A
Video	Y/chroma signal processing	HA118204F (IC201)	HA118203F (IC201)
	CCD 1H delay	MSM7476-76MS-KR1 (IC202)	MSM7470-72MS-KR1 (IC202)
	FM signal processing/EQ	Included in IC201	Included in IC201
	CNR	———	———
	Linear phase EQ	Included in IC201	Included in IC201
	Video AGC	———	———
FM audio	Audio signal processing	AN3962FB (IC501)	AN3964FB (IC501)
Preamp	Video head amp	HA118198F (IC1101)	HA118198F (IC1101)
	Audio head amp	LA7256 (IC1102)	LA7256 (IC1102)
MTS/OSD	MTS decoder	HTS7337A (IC1801)	HTS7337A (IC1801)
	OSD control/sync separator/AFC	Included in Main μP	Included in Main μP
Servo	Servo control	Included in Main μP	Included in Main μP
	FG/tach amp	Included in Main μP	Included in Main μP
System control	Main μP (system control μP)	HD6433977SB46F (IC901)	HD6433977SA70F (IC901)
	VCR-EEPROM	ST24C01 6 (FX621A) (IC903) ST24C02 6 (FX623A) (IC903)	ST24C01 (FX610A/FX611A) (IC903) ST24C02 (FX613A) (IC903)
	Loading motor drive	BA6209 (IC904)	BA6209 (IC904)
Timer	Timer μP	Included in Main μP	Included in Main μP
	Display driver	BU9716K (IC1701)	BU9716K (IC1701)
	Expander	———	———
	Auto clock	LC7455A (FX623A) (IC2901)	LC7455A (IC2901)
Power supply	5V regulator	M5278L05 (IC905)	M5278L05 (IC905)

Tips for Servicing

Trouble Display Function

This VCR has a function which displays mechanism malfunctions, etc. in the LCD display. Use this function to analyze the cause when the power is shut off due to a malfunction, etc. in the mechanism.
Two types of information are displayed, ① The operation mode when the malfunction occurred, ② Malfunction Codes.

Procedure to display a malfunction

Press the "CHANNEL ▼" button on the VCR when the power is turned off and hold it; the malfunction code is displayed while the button is held depressed.

The details of the malfunction are displayed as follows.

LCD DISPLAY



[Display of Details of Malfunction]

Displayed No.	Item	Details
"00"	No malfunction	
"01"	FL mechanism lock	Malfunction in insertion/ejection of cassette
"02"	Capstan lock	Malfunction of capstan motor drive during tape unloading
"04"	Reel lock	Reel rotation trouble when tape is running
"05"	Cylinder lock	Cylinder rotation malfunction
"07"	Loading mechanism lock	Malfunction in shifting mechanism mode
"16"	Servo lock	Shorting of 5V detected

[Mode Display when Malfunction Has Occurred]

Mode	Display	Mode	Display
Stop	No display	Forward search	SRCH
Fast forward	FF	Reverse search	−SRCH
Rewind	REW	Slow motion play	SLOW
Recording	REC	Reverse motion slow play	−SLOW
Recording pause	REC (flashes)	Still motion play	STILL
Reverse playback	−PLAY		

No symbols are displayed if the malfunction occurred when a cassette was inserted or ejected, or the power was switched on from off, and off from on.

How to Remove the Cassette when a Malfunction Has Occurred in the Mechanism

If a cassette is caught in the mechanism because of a malfunction in the mechanism, remove it by the following procedure.

(Work Procedure)
1. Remove the top cover.
2. Remove the front panel.

If the tape is wound round the cylinder in the loading state

Remove the spring and lift the pressure roller to pull it out.



1) Slacken the tape and release it from the tension pole, guide rollers, inclined guides and P out arm.



If the cassette does not come out from the FL mechanism in the unloading state.

1) Remove two screws holding the FL mechanism.
2) Hold the cassette lid with your fingers so the tape is not damaged and remove the FL mechanism.
3) Remove the slack tape and eject the cassette.



CUSTOMER CONTROLS

VCR Customer Controls



Item No.	Function	Page
1	POWER button	2
2	Infrared receiver	8
3	Cassette compartment	9
4	REC/IRT button	31
5	REW button	23
6	F.FWD button	23
7	PLAY button	24
8	STOP/EJECT button	9
9	CHANNEL (channel up/down)/ TRACKING buttons	31 23
	VCR Display	
10	AM/PM indicators	18
11	Time,	18
	Time counter,	28
	Tape remaining or	28
	VCR mode indicator	22
	PLAY — playback	22
	SRCH — double-speed play, visual search and skip playback ("–" appears during reverse direction viewing)	25
	SLOW — slow play	25
	REW — rewind	22
	S:REW— high speed rewind	23
	FF — fast forward	—
	S:FF — high speed fast forward	23
	STILL — play pause and frame advance	24
12	REM (tape remaining time) indicator	28
13	VCR, operate mode	—
14	Audio indicators	—
15	REC — record (flashes during record pause)	31
16	Tape-in indicator	9
17	TV channel or	31
	Auxiliary (L)	43
18	Delayed recording indicator	37

Accessories supplied

Check and identify the accessories supplied.
If any are missing or appear damaged, consult your dealer.



① Remote control
② Cable for connecting this VCR to a TV
③ Batteries for remote control handset (R6)

CUSTOMER CONTROLS

VCR Customer Controls



Item No.	Function	Page
19	AUDIO IN L, R jacks	41
20	VIDEO IN jack	43
21	IN FROM ANT. — signal input	10
22	OUT TO TV — signal out to TV	10
23	VIDEO OUT jack	11
24	AUDIO OUT L, R jacks	11

Remote Control Customer Controls



Item No.	Function	Page
1	Transmission window	8
2	POWER button	19
3	GUIDE — to recall OSD menu	19
4	DISPLAY — to recall on-screen display	27
5	CLEAR — clears time counter	29
6	VCR/TV mode select button	10
7	100/ENT button	31
8	VOL button — increase or decrease the audio volume	39
9	PROGRAM (programming) button	35
10	REW button — fast rewind or search	23
11	PLAY button — playback	20
12	REC — record button	31
13	STOP button — stops play/record function	20
14	PAUSE button	24
15	F.FWD button — fast forward or search	25
16	LAST CH button — switches to the TV channel you watched previously during the current viewing session.	39
17	CH (channel up/down) button	31
18	AVX button — select L	4
19	Number buttons	17
20	VCR, TV,CATV — device buttons let you set the remote to control one of the three devices	8

Instructions on Use and Description of New Functions

The following are extracts from the instruction manual.

[For VT-FX621A]

CUSTOMER CONTROLS

VCR Customer Controls



Item No.	Function	Page
1	POWER button	2
2	Infrared receiver	8
3	Cassette compartment	9
4	REC/IRT button	38
5	REW button	30
6	Infrared transmitter	26
7	F.FWD button	30
8	PLAY button	31
9	STOP/EJECT button	9
10	CHANNEL (channel up/down)/ TRACKING buttons	38 30
11	AUDIO IN L (mono), R jacks	54
12	VIDEO IN jack	54
	VCR Display	
13	AM/PM indicators	18
14	Time,	17
	Time counter,	35
	Tape remaining or	35
	VCR mode indicator	29
	PLAY — playback	29
	SRCH — double-speed play, visual search and skip playback ("–" appears during reverse direction viewing)	32
	SLOW — slow play	32
	REW — rewind	29
	S:REW— high speed rewind	29
	FF — fast forward	—
	S:FF — high speed fast forward	29
	STILL — play pause and frame advance	31
15	REM (tape remaining time) indicator	35
16	VCR, operate mode	—
17	Audio indicators	—
18	REC — record (flashes during record pause)	38
19	Tape-in indicator	9
20	TV channel or	38
	Auxiliary (L1/L2)	55
21	Delayed recording indicator	44

Accessories supplied

Check and identify the accessories supplied.
If any are missing or appear damaged, consult your dealer.



① Remote control
② Cable for connecting this VCR to a TV
③ Batteries for remote control handset (R6)

CUSTOMER CONTROLS

VCR Customer Controls



Item No.	Function	Page
22	AUDIO IN L, R jacks	53
23	VIDEO IN jack	55
24	IN FROM ANT. —'signal input	10
25	OUT TO TV — signal out to TV	10
26	VIDEO OUT jack	11
27	AUDIO OUT L, R jacks	11

Remote Control Customer Controls



Item No.	Function	Page
1	Transmission window	8
2	POWER button	22
3	GUIDE — to recall OSD menu	22
4	DISPLAY — to recall on-screen display	34
5	CLEAR — clears time counter	36
6	VCR/TV mode select button	10
7	100/ENT button	38
8	VOL button — increase or decrease the audio volume	52
9	PROGRAM (programming) button	42
10	REW button — fast rewind or search	29
11	PLAY button — playback	23
12	REC — record button	38
13	STOP button — stops play/record function	23
14	PAUSE button	31
15	F.FWD button — fast forward or search	32
16	LAST CH button — switches to the TV channel you watched previously during the current viewing session.	52
17	CH (channel up/down) button	38
18	AVX button — select L1 or L2	53
19	Number buttons	22
20	VCR, TV — device buttons let you set the remote to control one of the two devices	8

[For VT-FX623A]

0490

SERVICE MANUAL ABBREVIATION LIST

A	
ACC	Automatic Color Control
ACK	Automatic Color Killer
ADC B-Y	Analog to Digital Converted B-Y Signal
ADC R-Y	Analog to Digital Converted R-Y Signal
ADC Y	Analog to Digital Converted Luminance
ADD	Adder
ADRS	Address
A.DUB	Audio Dubbing
AF	Autofocus
AFC	Automatic Frequency Control
AGC	Automatic Gain Control
AGC KILLER	AGC Killer Voltage
ALC	Automatic Level Control
AIC	Automatic Iris Control
AM	Amplitude Modulation
AMP	Amplifier
APC	Automatic Phase Control
ASBL	Assemble (Phase Matching)
AUD.	Audio
AUX	Auxiliary
A5V	Always 5V B+ Source
B	
B (BLU)	Color Signal BLUE
BATT.	Battery
BF	Burst Flag
BG	Burst Gate or Back Ground
BGP	Burst Gate Pulse
BH	Power Supply for Selecting VHF High Band
BL	Power Supply for Selecting VHF Low Band
BLK	Blanking
BM	Power Supply for Selecting VHF Mid Band
BPF	Bandpass Filter
BS	Power Supply for Selecting VHF Super Band
BU	Power Supply for Selecting UHF Band
BU	Back-up
BUF.	Buffer Amplifier
B-YL	Battery
C	
C	Chroma
C (CHROMA)	Chrominance Signal
CAPST.	Capstan
CAS	Column Address Strobe
CARRI.	Carrier
CATV	Cable TV
C.BLANK	Chroma Blanking
C.BLK	Composite Blanking
CCD	Charge Coupled Device
CG	Character Generator
C.FG/CFG	Capstan Frequency Generater
C.FREE RUN	Chapstan Free Run
CH	Channel
CHD	Camera Horizontal Drive Pulse
CHAR.	Character
CHROMA	Chrominance
C.MEMORY	Counter Memory
CNR	Chroma Noise Reducer
COM.	Common
COM.	Composite
COMPA	Comparator
COMPE	Compensator
COMPO	Composite
COMP-EXP	Compressor-Expander
CONV.	Converter
CONT	Control
CORR.	Correlation
COUNT.	Counter
CP	Clamp Pulse
C.PAUSE	Camera Pause
C/R	Capacitor/Resistor
C.RESET	Counter Reset
C.REVERSE	Count Reverse
CST	Cassette

C	
C.SYNC	Composite Synchronizing Signal
CTL	Control Track Pulse (Control)
CYL	Cylinder
CY (CYAN)	Color Signal CYAN
D	
DA	Double Azimuth
D/A	Digital to Analog Converter
D-D	Direct Drive
DEEMPHA.	Deemphasis
DEF	Deflection
DEMOD.	Demodulator
DEMPX	Demultiplexer
DET	Detector
DIFF. AMP	Differential Amplifier
DISCRI.	Discriminator
DISP.	Display
DL	Delay Line
DN	Down
DO	Dropout
DOC	Dropout Compensator
DRAM	Dynamic Random Access Memory
D.REF 25/30	Delayed Reference 25/30Hz
D.SW 25/30	Delayed Switching 25/30Hz
DSP	Digital Signal Processor
DT/OE	Data Transfer/Output Enable
D/W	Dark/White
DWC	Delayed Write Clock
E	
EA-ROM	Electrically Alterable Read Only Memory
E-E	Electronic-to-Electronic
EMPHA.	Emphasis
EQ	Equalizer
EVF	Electronic Viewfinder
EXT.	External
F	
F.ADV	Frame Advance
F/V	Frequency-to-Voltage Converter
FB	Feed Back
FF	Flip Flop
F.FWD	Fast Forward
FG	Frequency Generator
FM	Frequency Modulation
FREQ.	Frequency
FRAME ADV	Frame Advance
Fsc	Color Sub Carrier Frequency
FWD	Forward
G	
GEN	Generator
GND	Ground
H	
H	Horizontal
HBF	Horizontal Burst Flag
HD	Horizontal Drive
Hi-Fi	High Fidelity
HLT	Halt
HPF	High-pass Filter
HPL	High-pass Limiter
HSS	Horizontal Sync. Separator
I	
IF	Intermediate Frequency
INC	Row Counter Increment
INDI.	Indicator
INT.	Internal
INV.	Inverter
I/O	In/Out (Input/Output)
IR	Infrared Rays
IRIS DET	Iris Detection
IRT	Instant Recording Timer
L	
LCD	Liquid Crystal Display
LIN.	Linear
LM	Loading Motor

L	
LNC	Line Noise Canceller
LOG	Logarithm
LP	Long Play
LP (H)	Long Play Signal (Active High)
LPF	Low-pass Filter
LUMA	Luminance
L/R	Left/Right
M	
MAN	Manual
M.BRAKE	Main Brake
M.CUT	Monitor Cut
MEM.	Memory
MEM ON	Memory ON
MEM SW	Memory Switch
MEM VIDEO	Memorized Video
MIX	Mixer
MMV	Monostable Multivibrator
MOD.	Modulator
MPX	Multiplex
MPX VIDEO	Multiplexed Video
M.STATE	Mechanism State
M.STOP	Memory Stop
MTS	Multi Channel Television Sound
N	
NEG	Negative
NFB	Negative Feed Back
NORM. or NOR.	Normal
NR	Noise Reduction
O	
OB	Optical Black
O/E	Odd/Even Field
OSC	Oscillator
OSD	On-Screen Display
P	
PB/PLAY	Playback
P.CONT	Power Control
PIF	Picture Intermediate Frequency
PG	Pulse Generator
P IN P	Picture in Picture
PIX MOVE	Picture Move
PLL	Phase Locked Loop
POS.	Positive
POWER CONT.	Power Control
PROG.	Program
PROTECT.	Protector
PWM	Pulse Width Modulation
R	
R (RED)	Color Signal RED
RAM	Random Access Memory
RAS	Row Address Strobe
RC	Reading Clock
RCC	Reading Clock Clear
RCR	Row Counter Reset
REC	Record
RECT.	Rectifier
REF	Reference
REF 25/30	Reference 25/30Hz from servo circuit
REG	Regulator
REL	Refresh Control
REW	Rewind
REV	Reverse
RF	Radio Frequency
RM	Reel Motor
ROM	Read Only Memory
R-YL	Color Difference Signal R-YL
S	
SAP	Second Audio Program
SAW	Sawtooth
SC	Serial Control
SC1 (0°)	3.58MHz Subcarrier Signal 1 (0-degree Phase Shifted)

S	
SC2 (90°)	3.58MHz Subcarrier Signal 2 (90-degree Phase Shifted)
SEP.	Separator
SG	Signal Generator
S/H	Sample and Hold
SIF	Sound Intermediate Frequency
SOL	Solenoid
SP	Standard Play
SP/LP	Standard Play/Long Play
S.REEL	Supply Reel Sensor
SRCH	Search
SRV	Servo
STABI.	Stabilizer
S.TRACK	Slow Tracking
STBY	Standby Mode
S-VHS	Super VHS
SW 15Hz	15Hz Head Switching Pulse
SW 25/30Hz	25/30Hz Head Switching Pulse
SYNC	Synchronizing signal
SYS.CON	System Control
T	
T (TELE)	Telephoto Angle
T.BRAKE	Take-up Brake
T/L	Tuner/Line
TP	Test Point
T.REEL	Take-up Reel Sensor
T.RESET	Timer Reset
TRS	Transfer
TμP	Timer Microprocessor
TU-μP	Tuning Microprocessor
U	
U/D	Up/Down
UNI.	Unified
V	
V (VERT)	Vertical
VAR	Variable
V.AGC	AGC Voltage
VCA	Voltage Controlled Amplitier
VCO	Voltage Controlled Oscillator
V.DRV	Vertical Drive Pulse
V.DUB	Video Dubbing
V/F	Voltage to Frequency Converter
VHS	Video Home System
VF	Focus Voltage
VOL.	Volume
V-REF	Voltage Reference
VP	Vertical Pulse
VSS	Vertical Sync. Separator
Vss	Voltage Super Source
VT	Tuning Voltage
VT-U	Tuning Voltage-UHF
VT-V	Tuning Voltage-VHF
VCXO	Voltage Controlled Crystal Oscillator
W	
WC	Write Clock
WCC	Write Clock Clear
WE	Weighting
WHT	Color Signal WHITE
WIDE	Wide Angle
WHD	Wide Horizontal Drive
WHT BAL CONT.	White Balance Control
Y	
Y	Luminance Signal
Y/C	Luminance/Chrominance
YE (YEL)	Color Singal YELLOW
YL	Luminance Signal (Low Component)
ANOTHER	
μP	Microprocessor
5V	ON 5V B+ Source
9V	ON 9V B+ Source

LEADLESS (CHIP) COMPONENT IDENTIFICATION

1. Leadless Transistor

The part name of a leadless transistor is indicated by a code on its surface, using one letter, one letter and one numeral, two letters, two letters and one numeral, two numerals, two numerals and one letter, three letters, or four letters.

Note: There are transistors with the same code but differnt part names, or with the same part name but different codes. Refer to the parts lists to finally identify a transistor.

CODE	PART NAME	CODE	PART NAME
Leadless (Chip) Transistor			
3925	2SC3925	BR	2SC2412K
1CQ	2SB902	BR	2SC4617
1D	2SC3127	BS	2SC2412K
1DS	2SD1328S	C-7	2SA811
1DT	2SD1328	C1G	XSC1623
1R	2SB970TX	CB	2SC3646
2BQ	2SK374PQ	CC	2SA1122C
2BR	2SK374QR	CC	2SC3647T
2Y	2SC3757	CC	2SC3647
2YQ	2SC4691	CD	2SA1122D
3N	2SK620	CE	2SA1122E
4N	XN5601	CK	2SD999
4Q	XN1B301	CP	2SC4097
4R	XN1C301	CQ	2SC2411K
5C	XN4601	CR	2SB710
5C	XP4601	CR	2SC2411
5H	XP4501	CR	2SB1219
5H	XN4501	D16	2SC1622A
5K	XP4401	D17	2SC1622A
5K	XN4401	D18	2SC1622A
5L	XN5501	DB	2SD1766
5N	XN6501	DE	2SC2463
5O	XN6401	DF	2SD1623
5R	XP1501	DF	2SD1898
5R	XN1501	DG	2SD1624
5S	XN1504	DK	2SB798
5V	XN1401	EC	2SA1022
5W	XN2501	F-2	2SC1009F2
5X	XN4504	F-3	2SC1009F3
7R	XN2401	F-4	2SC1009F4
7S	XN1601	FC	2SC2619
AA	2SD1757K	FR	2SA1774
AKQ	2SA1738	FR	2SA1037K
AKQ	2SA1806	FR	2SA1576R
AL	2SA1791	FS	2SA1037K
AM	2SC4656	GC	2SC2734
AO	2SB709AQR	GM	3SD1615
AQ	2SB709AQ	HQ	2SA1C36K
AQ	2SB766	IC	2SC3016
AR	2SB1462	IRD	2SA1484
AR	2SB766	IS	2SB792S
AR	2SB709ARS	IT	2SB792T
AR	ASB1218R	L-4	2SC1623L4
AS	2SB766	L-5	2SC1623L5
AS	2SB709AS	L-6	2SC1623L6
B3	2SC1621B3	L-6	2SC2812L6
B4	2SC1621B4	L-7	2SC2812L7
BC	2SB1188	L5	MMBC1623L5
BD	2SB1121	L6	MMBC1623L6
BE	2SB1260	LB	2SC2462B
BF	2SB1123	LC	2SC2462C
BF	2SB1308	LD	2SC2462D
BG	2SB1124	LR	2SC2412KLN
BH	2SB1001	M-5	2SA812
BQ	2SB709A	M-6	2SA1179
BR	2SC4081R	MC	2SA1052MC
MD	2SA1052MC-D	ZS	2SD874S
N3	2SC1653	VR	2SD968A
ND	2SD1306ND	W1	FMW1
NE	2SD1306NE	W10	FMW10
PD	2SA1171D	W2	FMW2
PS	2SD814	W3	FMW3
QB	2SC2620QB	WR	2SD602
QC	2SC2620QC	X1	UMX1
QO	2SC2714	X1	IMX1
R22	2SC4226	X2	IMX2
R22	2SC3356	Y1	FMY1
R32	2SC4227	Y12	2SA1464
R34	2SC3583	Y25	NTM3906
R42	2SC3585	Y3	FMY3
RB	2SC2618RB	YCD	2SK197
RC	2SC2618RC	YI	2SA1666
RK	2SC3357	YQ	2SD601YQ
S1	FMS1	YR	2SD601YR
S2	FMS2	YR	2SD1819R
SC	2SA1121	YR	2SD2216
SO	2SA1162	YS	2SD601YS
SP	2SC3082K	Z1	IMZ1
T1	IMT1	Z2	IMZ2
T1	UMT1	ZO	2SD874T
T2	IMT2	ZQ	2SD601A
UD	2SC2404	ZR	2SD874R
Digital Transistor			
3	DTC143TK	6C	UN9113
4	DTC114TK	6S	XP4113
6	DTC144TK	8B	UN5212
13	DTA143EK	8C	UN9213
14	DTA144EK	8C	UN2213
15	DTA124K	8S	XP4213
15	DTA124EU	9L	XP1213
16	DTA144EU	9L	XN1213
16	XDA144EK	A1	FMA1
16	DTA144EE	A1	UMA1
23	DTC143EK	A2	FMA2
24	DTC114EU	B2	UMB2
24	DTC144EK	B2	IMB2
25	DTC124EU	C2	FMC2
25	DTC124K	C5	FMC5
26	DTC144EE	D2	IMD2
26	DTC144EU	F52	DTB123
26	XDC144EK	G1	FMG1
33	DTA143XK	G2	FMG2
43	DTC143XK	G21	DTD113ZK
52	DTA123YK	G5	FMG5
60	UN511F	HO3	DTC343TK
64	DTC114YK	H2	IMH2
80	UN521F	H2	UNH2
4P	XN1A312T	H27	DTC363EK
6B	UN5112	RO4	KSR1104
6C	UN2113	R31	FP1L2Q
FET			
30	2SK621	WS	2SK322T
1FQ	2SK321FQ	WT	2SK322T
1FR	2SK321FQR	X15	2SK425
1KP	2SK316	X4	2SK94
2BQ	2SK663	XAF	2SK980FG
DY	2SK1579	YC	2SK197YC
JO	2SK208	YD	2SK197YD
K	3SK166	YE	2SK197YE
K4	2SK160K4	ZD	2SK217ZD
K5	2SK160K5	ZE	2SK217ZE
KB	2SK323		

(1) Identification with two letters

Use this code and the following chart for transistor identification.

Example :

Code	Part name
CD	2SA1122D
LD	2SC2462D



(2) Identification with one letter and one numeral

Use this code and the following chart for transistor identification.

Example :

Code	Part name
L5	2SC1623(5)
L6	2SC1623(6)



Example :

Code	Part name
1D	2SC3127D



Note: Codes S1, S2, T1, W1, W2, W3, X1, Y1, Y3, Z1 and Z2 encode only the part names.

(3) Identification with one numeral and two letters

Use this code and the following chart for tarnsistor identification.

Example :

Code	Part name
1FQ	2SK321Q



(4) Identification with one letter and two numerals

Use this code and the following chart for transistor identificaion.

Example :

Code	Part name
R25	2SC3356



(5) Identification with to letters and one numeral

Use this code and the following chart for transistor identification.

Example :

Code	Part name
DV5	2SD596



(6) Identification with three letters

Use this code and the following chart for transistor identification.

Example :

Code	Part name
AAS	2SD1757KS



2. Leadless Diode

The part name of a leadless diode is indicated by a code on the surface, using one letter and one numeral, two letters, two letters and one numeral, two numerals and one letter, or three numerals. Use this code and the following table to identify the part name of a diode.

Note: Refer to the parts lists to finally identify a diode.

CODE	PART NAME	CODE	PART NAME
Diode			
0	HVU300A	3D	RB715F
1.0	1SV201	3.0L	MA3030L
2.0	MA3020	3.6L	MA3036L
5.1	MA3051L	3.9L	MA3039L
5.1	MA3051M	4.3H	MA3043H
6.8	MA3068	4.3L	MA3043L
6.8	MA3068M	4.3M	MA3043M
7.5	MA3075L	4.7L	MA3047L
8.2	MA3082M	4.7M	MA3047M
9.1	MA3091	5.1H	MA3051H
20	HZM6	5.1L	MA3051L
24	1SV221	5.1M	MA3051M
27	RD2.7M B	5.6M	MA3056M
30	RD3.0M B	6.2L	MA3062L
51	RD5.1M B2	6.2M	MA3062M
56	RD5.6M B	6.8H	MA3068H
91	RD9.1M B	6.8L	MA3068L
102	RD10M B2	6.8M	MA3068M
122	RD12M B2	6.8M	MA3068
163	RD16M B3	7.5H	MA3075H
182	RD10M B2	7.5L	MA3075L
271	RD2.7M B	8A	UN221D
272	D2.7M B2	8.2H	MA3082H
301	RD3.0M B	8.2M	MA3082M
362	D3.6M B2	9.1M	MA3091M
391	D3.9M B1	9.1M	MA3091
512	RD5.1M B2	10L	MA3100L
561	RD5.6M B	10M	MA3100M
621	RD6.2M B1	11L	MA3110L
681	RD6.8M	12M	MA3120M
683	RD6.8M B3	13H	MA3130H
911	RD9.1M B	18M	MA3180M
2.7H	MA3027H	36M	MA3360
Zener Diode			
1A	MA110	M3A	MA199
A3	1S2835	MC	MA153
A4	HSM2836C	MC	MA143
A5	1S2837	MH	MA141K
A6	HSM2838C	MH	MA151K

CODE	PART NAME	CODE	PART NAME
	Zener Diode		
B	SB0505CP	MH	MA152K
B64	SFPB64	MI	MA132K
B74	SFPB74	MN	MA141WA
BE	1SV172	MN	MA152WK
C1	HSM88S	MN	MA151WA
C2	HSM276S	MO	MA132WA
C3	1SS226	MO	MA152WA
C4	HSM88WK	MP	MA133
F7	KV1470	MT	MA151WK
H5	HVM14	MT	MA141WK
J	SB07-03C	MU	MA132WK
K	DA221	MU	MA151WA
M1A	MA159	N	DAN222
M1C	MA158	N	DAN202T
M1M	MA721	NU	MA152WK
M1N	MA713DAT	P	DAP202T
M1P	MA714	S4	D1FS4
M2A	MA122	SA	SB10-05P
M2B	MA123	Z	DA106K

3. Leadless Resistor
The resistor value is indicated on its surface, using three numerals, or one letter and one numeral.

(1) Identification with three numerals
Read this code following the same procedure as when reading the color code on discrete resistors.

Example :

code	value
330	33 x 10^0 = 33 ohms
561	56 x 10^1 = 560 ohms
123	12 x 10^3 = 12K ohms
1R2	1 + 0.2 = 1.2 ohms (R : Decimal point)



(2) Identification with one letter and one numeral
Use this code and the following chart for resisitor identification.

Letter	Value	Letter	Value	Letter	Value
A	1	J	2.2	S	4.7
C	1.2	L	2.7	U	5.6
E	1.5	N	3.3	W	6.8
G	1.8	Q	3.9	Y	8.2

Example :

code	value
A1	1 x 10^1 = 10 ohms
G2	1.8 x 10^2 = 180 ohms
L3	2.7 x 10^3 = 2700 ohms
S4	4.7 x 10^4 = 47K ohms
W5	6.8 x 10^5 = 680K ohms



4. Leadless Capacitors
The capacitor value is indicated on its surface, using body color and one letter, or one letter and one numeral.

(1) Identification with body color and one letter



Body Color	Letter	Value	Body Color	Letter	Value
Red	A	1(PF)	Blue	A	100(PF)
	C	2		C	120
	E	3		E	150
	G	4		G	180
	J	5		J	220
	L	6		L	270
	N	7		N	330
	Q	8		Q	390
	S	9		S	470
Black	A	10(PF)		U	560
	C	12		W	680
	E	15		Y	820
	G	18	White	A	0.001(μF)
	J	22		E	0.0015
	L	27		J	0.0022
	N	33		L	0.0027
	Q	39		N	0.0033
	S	47		S	0.0047
	U	56		W	0.0068
	W	68	Green	A	0.01(μF)
	Y	82		E	0.015
				J	0.022
				N	0.033
				S	0.047
				U	0.056
				W	0.068
				Y	0.082
			Yellow	A	0.1(μF)

Example : Color	Letter	Value
Red	A	1PF
Black	A	10PF

(2) Identification with one letter and one numeral



Letter/Numeral	Value	Letter/Numeral	Value
A0	1(PF)	A2	100(PF)
H0	2	C2	120
M0	3	E2	150
d0	4	G2	180
f0	5	J2	220
m0	6	L2	270
n0	7	N2	330
t0	8	Q2	390
y0	9	S2	470
A1	10(PF)	U2	560
C1	12	W2	680
E1	15	Y2	820
G1	18	A3	0.001(μF)
J1	22	E3	0.0015
L1	27	J3	0.0022
N1	33	N3	0.0033
Q1	39	S3	0.0047
S1	47	W3	0.0068
U1	56	A4	0.01(μF)
W1	68	E4	0.015
Y1	82	J4	0.022
		N4	0.033
		S4	0.047
		U4	0.056
		W4	0.068
		A5	0.1

Example :

Letter/Numeral	Value
A0	1PF
A1	10PF

5. Leadless Jumper
The leadless jumper is indicated as shown below.

(1) (2) (3) (4)



CHAPTER 2 DISASSEMBLY

1. Before Starting Disassembly

1) Unplug the power cord from the AC outlet.
2) [Removal procedure]
If a special procedure is required when dismantling any component, it is indicated using numbers. Follow the numbers (①, ②, ③ ...) shown in the illustrations.
[Reinstallation procedure]
Reinstall each component in the reverse order to removal when otherwise not specified.
3) Insert card connectors securely all the way as they are of the direct insertion type.

Identifications of Circuit Boards



Fig. 1-1

2. Disassembly Method

When replacing defective parts, first refer to the "parts hierarchy chart" shown below.
This chart shows the procedure for parts removal when replacing defective parts.

[How to use the parts hierarchy chart]
(1) Locate the part to be replaced.
(2) Check the parts in the ranks above the part to be replaced and start dismantling.
(3) Replace the defective part and reinstall the parts in the reverse order to that shown in the parts hierarchy chart.

Parts Hierarchy Chart

Note: Dismantle parts in the eject state.



Disassembly Procedure Diagrams

Item	Parts to remove
2-1	Top cover, front panel, rear panel and US-FL mechanism

◆ Caution when reinstalling the US-FL mechanism
Reinstall the US-FL mechanism in the state that the cassette holder is pulled forward.
(Otherwise, the switch arm could damage the FL switch on the MAS board.)



Fig. 2-1

2-2	Cassette door and buttons

◆ Caution when reinstalling the front panel
Reinstall the front panel in the state that the cassette door is pushed so the boss of the door arm comes to the front of the boss support of the cassette door.



Fig. 2-2

Item	Parts to remove		
2-3	LED board (For VT-FX623A)	2-4	Front frame and LCD board



Fig. 2-3



Fig. 2-4

2-5	US mechanism/MAS board assembly



Fig. 2-5

Item	Parts to remove
2-6	Separation of MAS board from US mechanism



Fig. 2-6

Procedure to remove only the US mechanism

With this VCR the US mechanism can be removed without removing the MAS board. This is done by a different method from the normal disassembly method.

Parts to remove	Item
Top cover, Front panel and Rear panel	2-1
⇩	
US-FL mechanism	2-1
⇩	
Remove two screws on the bottom of the VCR.	2-7
⇩	
Remove five screws holding the US mechanism.	2-7
⇩	
Disconnect the connectors on the US mechanism and list the mechanism.	

2-7 Procedure to remove only the US mechanism



Fig. 2-7

3. Cautions When Reinstalling the US Mechanism

This VCR has mechanism sensors on the MAS board and the capstan and loading motors are connected via direct connectors. Therefore, when reinstalling the US mechanism, observe the following cautions.



Fig. 3-1

(1) Align the ▽ mark and mode no. 1 of the mechanism state switch on the MAS board. (Mode no. 1 of the mechanism state switch has a click position.)

(2) Check that mode no. 1 on the P drive gear in the mechanism and the ▽ mark of the spring hook are aligned. If they are not aligned, turn the loading motor pulley to align them.

(3) Pass the end LED through the hole in the mechanism and install the mechanism from immediately above using the installation position holes as reference. Check that the boss of the mechanism state switch and the hole in the cam gear are aligned.

(4) Push the terminal sections (shaded sections ▨) of the capstan and loading motors and check that they are inserted securely.



Fig. 3-2

CHAPTER 3 ELECTRIC CIRCUIT ADJUSTMENT

Servicing Positions

1. Servicing position during electrical adjustment

Perform electric adjustments of this VCR after removing the top cover, front panel and rear panel.

When the shield cover of the connector between the cylinder motor and MAS circuit boards is removed, noise appears in the played back picture.
Attach the shield cover when checking the picture on the screen.



Fig. 1

2. Servicing positions when repairing and checking circuits

2-1. Procedure to set the LCD and LED boards to the servicing positions (Fig. 2)

1) Remove the top cover and front panel.
2) Remove the rear panel.
3) Remove the LCD and LED boards and front frame, then reattach the LCD and LED boards.



Fig. 2

2-2. Procedure to set the MAS board to the servicing position (Fig. 3)

1) Remove the top cover, front panel and rear panel.
2) Remove the US-FL mechanism and front frame.
3) Remove the MAS board, with the LCD and LED boards and US mechanism assembled from the frame.
4) Turn over the MAS board and perform checks from the pattern side indicated by the arrow.
   Be careful of the following at this time.
   - Lay out an insulation sheet under the boards.
   - Attach the shield cover at the rear of the cylinder.

   Attach the US-FL mechanism when loading the tape.



Fig. 3

3. Be careful of electric shocks

The power supply block on the right of the VCR has a heat sink which generates a high voltage. "HIGH VOLTAGE" is printed on the heat sink.
Take great care when handling this heat sink when the power is turned on during servicing.



Fig. 4

Electrical Circuit Adjustment

1. Test equipment/jigs necessary for adjustment

1) Dual-trace oscilloscope
2) Color bar generator
3) Voltmeter
4) Monitor TV (with A/V jacks)
5) Alignment tapes:
   - NTSC tape: Part No. 7099046
   - 30HMP2-1 : Part No. 7099089
   - 24HMAF-2 : Part No. 7099153 (Hi-Fi alignment tape)
6) Blank tape
7) C/R oscillator

2. Cautions on adjustment

1) The following conditions apply when otherwise not specified.
   - Probe of oscilloscope: 10:1
   - Synchronization of oscilloscope: Internal sync
   - Ground of test equipment: PG2508 pin 6 (on MAS board)
2) When performing more than one adjustment, follow the specified order.

3. Tips for adjustment

3-1. Procedure to reset the main microprocessor

The main microprocessor is not reset even when the power cord is unplugged from the AC outlet because its power is backed up by a backup circuit. Press S708 on the MAS board to reset the entire microprocessor.
Do not press the reset switch with the power cord unplugged from the AC outlet as the slow tracking preset value could drift.
If the preset value drifts, plug the power cord into an AC outlet and press the reset switch again with the power turned on.
It is recommended that you press the reset switch after reinstalling the front panel.



Fig. 5

3-2. Procedure to switch off the blue background function

1) Press the "GUIDE" button of the remote control to display the menu on the monitor TV screen.
2) Press 2 to select the VCR setup screen.
3) Press 1 to specify blue background off.

3-3. Procedure to obtain the EP head playback mode (X-value adjustment test mode)

Press the "1" and "4" buttons of the remote control provided simultaneously when an alignment tape is being played and hold them, then press the "CHANNEL ▽" button on the VCR; The VCR enters the EP head playback mode (X-value adjustment test mode).

4. Connections of test equipment

- Connect the test equipment as follows when otherwise not specified.

1) Connect a color bar generator to the video input 1 jack of the VCR.
2) Connect a monitor TV to the video output 1 jack of the VCR.
3) Connect a monitor TV (able to handle a stereo signal) to the audio output 1 jack.
4) Connect an antenna to the antenna jack and receive a TV broadcast (only for sound multiplex adjustment).

Test Points and Adjustment Points



Fig. 6 MAS (Main) Circuit Board (Components Side)

The remote control provided with this VCR does not have a tracking button. The "CHANNEL △" and "▽" buttons operate as the tracking controls during playback.

5. Servo Circuit Adjustments

5-1. Switching point adjustment (Fig. 6)

Purpose: To set the switching point of the video heads during playback to the center where the CH-1 and CH-2 envelopes overlap each other.		Fault due to incomplete adjustment: • Vertical sync signal is degraded and vertical jitter occurs. • Switching noise appears across the bottom of the screen.	
Test Equipment/Jigs	Test Equipment Connection Points	State of VCR	Adjustment Point
• Oscilloscope • Alignment tape (30HMP2-1)	• CH-1: Video out jack • CH-2: PG2508-8(SW30Hz)	1) Play the alignment tape 2) Set to the X-value adjustment test mode.	• F.FWD button (S702) • REW button (S703)

Adjustment Procedure
1) Play the alignment tape.
2) Press the "1" and "4" buttons of the remote control provided simultaneously and hold them, then press the "CHANNEL ▽" (S707) button of the VCR to set the VCR to the test mode. (SP is switched to LP in the display.)
3) Press the "F.FWD" and "REW" buttons of the remote control so the phase from the vertical sync to the trailing edge (trigger position) of the SW30Hz pulse is set to 6.5H±0.5H.
4) Press the STOP button to release the test mode.

Waveforms



<Conditions of oscilloscope>
• Trigger with CH-2.
• Set the sync slope to "-".

5-2. X-value adjustment (Fig. 6)

Purpose: To ensure compatibility with other VCRs.		Fault due to incomplete adjustment: • When a tape recorded by another VCR is played back, the tracking is not optimized and noise appears on the screen.	
Test Equipment/Jigs	Test Equipment Connection Points	State of VCR	Adjustment Point
• Oscilloscope • Alignment tape (30HMP2-1)	• CH-1: PG2508-1 (PB FM) • CH-2: PG2508-8 (SW30Hz)	1) Play the alignment tape. 2) Set to the X-value adjustment test mode.	• Groove for adjustment the X-value

Adjustment procedure
1) Play the alignment tape.
2) Press the "1" and "4" buttons of the remote control provided simultaneously and hold them, then press the "CHANNEL ▽" (S707) button of the VCR to set the VCR to the test mode. (SP is switched to LP in the display.)
3) Loosen the screw holding the A/C head base (do not loosen it excessively).
4) Insert a screwdriver into the groove for adjusting the X-value and adjust so the FM output is maximum. There are two maximum FM output points when the groove for adjusting the X-value is turned. Adjust the FM output to a maximum when the groove is at the correct position as shown in the figure below.
5) Press the STOP button to release the test mode.

Waveforms





5-3. Vertical jitter adjustment

Purpose: • To suppress vertical jitter during slow and still play.		Fault due to incomplete adjustment: • Vertical jitter appears in the picture during slow and still play.	
Test Equipment/Jigs	Test Equipment Connection Points	State of VCR	Adjustment Point
• Monitor TV • Color bar generator • Blank tape	• Video output jack • Video input jack	• Record a color bar signal and play it using the same VCR.	• CHANNEL △ (S706) • CHANNEL ▽ (S707)
Adjustment procedure <EP vertical jitter correction>: Record in the EP mode and play it back using the same VCR. 1) Press the PAUSE button to set the VCR to the still play mode. 2) Use the CHANNEL buttons of the VCR to suppress vertical jitter of the picture.		<SP vertical jitter correction>: Record in the SP mode and play it back using the same VCR. 1) Press the PAUSE button to set the VCR to the still play mode. 2) Use the CHANNEL buttons of the VCR to suppress vertical jitter in the picture.	

5-4. Forward slow tracking preset adjustment

Purpose: To adjust the timing with which the brake pulse of the capstan motor is generated during slow play so that noise is minimum.		Fault due to incomplete adjustment: • Noise appears during slow play and the picture is not clear.	
Test Equipment/Jigs	Test Equipment Connection Points	State of VCR	Adjustment Point
• Monitor TV • Color bar generator • Blank tape (T-120)	• Video output jack • Video input jack	• Slow tracking: Unplug the power cord to set the slow tracking to the center.	• CHANNEL △ (S706) • CHANNEL ▽ (S707)
Adjustment procedure 1) Record a signal on the middle of a T-120 blank tape in the EP mode and play it back using the same VCR. 2) Press the "1" and "4" buttons of the remote control (provided) simultaneously during playback and hold them, then press the "PLAY" button (S701) to set the VCR to the forward test slow mode. 3) Press the CHANNEL buttons so the slow feed noise appears across the bottom of the monitor screen and then it is driven out from the bottom of the screen.		4) Check that no noise appears on the monitor screen. 5) Press the "PLAY" button to return the VCR to the playback mode (the preset data is written to the EEPROM). 6) Perform the same procedure to perform slow tracking preset adjustment in the SP mode. Do not press the reset switch after adjustment when the power is not turned on as the preset value could drift. If the preset value drifts, turn the power on and press the reset switch again for recovery.	

5-5. Reverse slow tracking preset adjustment

Purpose: To adjust the timing with which the brake pulse of the capstan motor is generated during reverse slow play so that noise is minimum.		Fault due to incomplete adjustment: • Noise appears during reverse slow play and the picture is not clear.	
Test Equipment/Jigs	Test Equipment Connection Points	State of VCR	Adjustment Point
• Monitor TV • Color bar generator • Blank tape (T-120)	• Video output jack • Video input jack	• Slow tracking: Unplug the power cord to set slow tracking to the center.	• CHANNEL △ (S706) • CHANNEL ▽ (S707)
Adjustment procedure 1) Record a signal on the middle of a T-120 blank tape in the EP mode and play it back using the same VCR. 2) Press the "1" and "4" buttons of the remote control (provided) simultaneously during still play and hold them, then press the "PLAY" button (S701) to set the VCR to the reverse test slow mode. 3) Press the "CHANNEL" buttons so the slow feed noise appears across the bottom of the monitor screen and then it is driven out from the bottom of the screen.		4) Check that no noise appears on the monitor screen. 5) Press the "PLAY" button to return the VCR to the playback mode (the preset data is written to the EEPROM). 6) Perform the same procedure to perform reverse slow tracking preset adjustment in the SP mode. Do not press the reset switch after adjustment when the power is not turned on as the preset value could drift. If the preset value drifts, turn the power on and press the reset switch again for recovery.	

6. Audio/MTS Circuit Adjustments

6-1. Hi-Fi audio playback level check

Purpose: To set the playback level of the Hi-Fi audio signal to the specified value.		Fault due to incomplete adjustment: • The appropriate volume cannot be obtained during playback.	
Test Equipment/Jigs	Test Equipment Connection Points	State of VCR	Adjustment Point
• Voltmeter • Hi-Fi alignment tape (24HMAF-2)	• When checking L-CH: Audio output (L) jack • When checking R-CH: Audio output (R) jack	• Play Hi-Fi alignment tape.	———
Adjustment procedure Use the same checking procedure for both the L and R channels. Check that the voltmeter reads -7.8dBs±3.0dBs. If it cannot be confirmed, check the playback signal system.			

6-2. MTS input level adjustment

Purpose: To set the level of the MPX signal supplied to the MTS processor in IC1801 from the tuner/IF to the specified level.		Fault due to incomplete adjustment: • The S/N deteriorates or distortion becomes conspicuous. • Stereo separation deteriorates.	
Test Equipment/Jigs	Test Equipment Connection Points	State of VCR	Adjustment Point
• MTS sound signal generator • Voltmeter	• IN FORM ANT • PG2509-2	• E-E mode	• RT1801
Adjustment procedure 1) RT1801: Set the reading of the voltmeter to -20.0dBs±0.5dBs. Notes: MTS sound signal generator settings: • Audio frequency: 300Hz • Modulation signal: L+R Monitor TV settings: • Press the "GUIDE" button of the remote control to display the menu on the monitor TV screen. • Press 2 of the remote control. • Press 6 of the remote control to select the SAP option and switch it from OFF to ON.			

List of Data in EEPROMs and Initial Settings

This VCR uses two EEPROMs. The table below lists the data stored in each ROM. It also shows the data set by shipment mode initialization, when the tape navigation map data is initialized and when the trouble display is cleared.

Information	Data memory ROMs		List of initial data	Remarks
	IC903 EEPROM	Shipment mode initial data	Clearing of trouble display	
Guide channel data	○			
Channel memory	○	○		
VCR mode select data	○	○		
Trouble display data	○	○	○	
Slow tracking data	○	× (set by adj.)		
Artificial V sync data	○	× (set by adj.)		
Switching point data	○	× (set by adj.)		
Auto clock	○	○		For VT-FX623A

List of Hidden Commands

The following tables list the mode setting commands during adjustment and EEPROM initial setting commands.

1. Mode setting commands during adjustment

Item	Mode in which command is accepted	Operation	Remarks
Tracking center	Play	Press the "CHANNEL △" and "▽" buttons on the VCR or the "1" and "4" buttons of the remote control simultaneously.	
X-value adjustment test mode	Play	Press the "1" and "4" buttons of the remote control simultaneously and press the "CHANNEL ▽ " button on the VCR.	
Forward test slow mode	Play	Press the "1" and "4"buttons of the remote control simultaneously and press the "PLAY" button on the VCR.	
Reverse test slow mode	Still play	Press the "1" and "4" buttons of the remote control simultaneously and press the "PLAY" button on the VCR.	

2. EEPROM initialization commands

Item	Mode in which command is accepted	Operation	Remarks
Shipment mode initial setting	EJECT	Press the "REC" button on the VCR and hold it, then press the "RESET" button used to initialize the microprocessor.	Hold the "REC" button depressed and release it after the display lights.
Clearing of trouble display	——	Press the "PLAY" button on the VCR and hold it, then press the "RESET" button used to initialize the microprocessor.	Hold the "PLAY" button depressed and release it after the display lights.

Initial Settings of IC903 (EEPROM)

The following shows the on-screen display and modes of switches when IC903 (EEPROM) is initialized.

```
[A] VCR SETUP MENU (in menu)
   1  AUTO BLUE          [ ON ]
   4  AUDIO SETUP        [Hi-Fi]
   5  AUDIO SETUP        [STEREO]
   6  AUDIO SETUP        [SAP OFF]
[B] CLOCK SET (in menu)(For FX623A)
   1  CLOCK SET          [AUTO]
   3  SET TIME ZONE      [AUTO]
   4  SET D.S.T          [AUTO]
[C] CHANNEL PRESET (in menu)
   1  CHANNEL                [CATV1]
[D] Front panel switches
   ANT. OUT       : RF-3
```

Caution When Replacing IC903 (EEPROM)

After replacing IC903 (EEPROM), execute the VCR initial settings and then perform the following adjustments.

	Adjustment	Page
1	Vertical jitter adjustment	P3-5
2	Forward slow tracking adjustment	P3-5
3	Reverse slow tracking adjustment	P3-5

CHAPTER 4 EXPLODED VIEWS

1. CABINET SECTION



NOTE: THE SYNTHETIC RESIN MEMBERS THAT CAN BE DISMANTLED ARE SHOWN BY ABBREVIATIONS USING LETTERS.

2. US-MECHANISM (TOP VIEW) SECTION

Ⓜ = MOLICOAT (PG-641)
Ⓢ = SONIC SLIDAS OIL (#1600)



3. US-MECHANISM (BOTTOM VIEW) SECTION



4. US-FL MECHANISM SECTION

Ⓜ = MOLICOAT (PG-641)
Ⓖ = SILICONE (G-332)



CHAPTER 5 REPLACEMENT PARTS LIST

1. MECHANICAL PARTS LIST

SYMBOL-NO	P-NO	DESCRIPTION
		FOR FINAL ASSEMBLY
101	0A11161	COVER,TOP (HEPM)
102	PH13122	PANEL,FRONT (HEPM) [FX621A]
102	PH13126	PANEL,FRONT (HEPM) [FX623A]
106	NT10483	PIECE,FRONT (HEPM)
107	PH13321	DOOR,CASSETTE (HEPM)
108	KL11451	SPRING,DOOR (HEPM)
△111	EV10271	CORD,POWER (HEPM)
114	MO10199	CUSHION,RUBBER
117	0A11141	COVER,BOTTOM
118	MD11281	COVER,CBA
119	PH13241	PANEL,REAR (HEPM)
139	4826834	SPRING,EARTH
140	MD11602	PLATE,EARTH
203	KX11661	CLEANING,HEAD
205	GP10252	MOTOR,CAPSTAN
206	KX12294	BASE,GUIDE ROLLER (I)
210	KX12302	BASE,GUIDE ROLLER(O)
212	KX11531	ARM,TENSION
213	KL10662	SPRING
214	KX11631	BAND,TENSION
215	KF10641	GEAR,DRIVE
216	KF10701	GEAR,IDLER
217	KX12661	ARM,OUT
218	KX11581	GEAR,SPIRAL
219	KX11553	ARM,PINCH ROLLER
220	KX11451	BASE,CYLINDER
221	KX11941	AC HEAD
223	5423082	FE HEAD
224	KL10711	SPRING
225	KX11591	GEAR,LOADING(L)
226	KX11611	GEAR,LOADING(R)
227	KF10673	GEAR,CAM
228	4344643	WASHER
229	KX11443	PULLEY
230	KX11522	BELT
231	KF10631	FLANGE
232	KX12031	BRAKE
233	KF10571	GEAR,CHANGE
234	KL10771	SPRING
235	KX12001	STOPPER,SPRING
236	KF10561	GEAR,IDLER
237	KX11831	ARM,OPERATION
238	KX11362	SLIDER
239	KF10551	GEAR,TRANS
240	KF10501	GEAR,DRIVE
241	KL10773	SPRING
242	KF10513	GEAR,CHANGE
243	KX11411	ARM,CHANGE
244	KX11371	GEAR
245	KX11892	MOTOR,LOADING
246	KF10521	GEAR,IDLER 1
247	KF10532	GEAR,IDLER 2
248	KH10152	REEL,TABLE(S)
249	KX11423	ARM
250	KH10161	REEL,TABLE(T)
251	KX11991	STOPPER
252	KX11861	BRAKE
253	KL10782	SPRING,BRAKE
254	KX11875	BRAKE,L
255	KX11883	BRAKE,R
256	KL10792	SPRING,BRAKE
257	KF10542	GEAR,JOG
258	KX13132	ARM,JOG
259	KX11841	ARM,REC
260	6542462	SPRING
261	KX11811	BRAKE,SUB
262	KL10903	SPRING,SUB
263	KX12461	BRACKET,BASE
264	MN11571	WASHER
265	KL11062	SPRING,JOG
401	KX11772	BRACKET (R)
402	KF10682	GEAR 1
403	KF10691	GEAR 2
404	KX11751	ARM,DOOR
405	KX11761	ARM,SWITCH
406	6323723	SPRING
407	KX11931	ARM,DRIVE
408	KX11921	HOLDER,CASSETTE
409	KX11741	BRACKET(L)
501	HX10295	CYLINDER ASSY (CY-U6N1)
901	8699410	SCREW(3X10)
902	8679408	SCREW (3.0X8)
903	8671306	SCREW(2.6X6)
904	7781132	BT SCREW
905	7784323	SCREW(3X8)
951	8652408	SCREW (PSW3X8)
952	0671310	DT SCREW-2.6MMDX10MM
953	0671306	DT SCREW 2.6MMDX6MM
954	8691306	BT SCREW 2.6MM
956	KX12443	SCREW
957	MJ10341	SCREW(M2.6)
958	0671308	DT SCREW-2.6MMDX8MM
959	0671305	DT SCREW-2.6MMDX5MM
		FOR ACCESSORIES
802	EW10251	CORD,RF
803	HL10624	REMOTE HAND SET(VT-RM621A)(HEPM)[FX621A]
803	HL10625	REMOTE HAND SET(VT-RM623A)(HEPM)[FX623A]

2. ELECTRICAL PARTS LIST

SYMBOL-NO	P-NO	DESCRIPTION
		CAPACITORS
C0201	0893008	CERAMIC CHIP 0.1UF +-10% 16V
C0204	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C0205	0893031	CERAMIC CHIP 1000PF+-10% 50V
C0208	0893082	CERAMIC CHIP 0.022UF+80-20% 50V
C0209	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C0211	0800138	ELECTROLYTIC 47UF 6.3V
C0212	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C0213	0254458	ELECTROLYTIC 3.3UF+-20% 50V
C0214	0893082	CERAMIC CHIP 0.022UF+80-20% 50V
C0215	0800115	ELECTROLYTIC 3.3UF 50V
C0216	0209948	CERAMIC CHIP 330PF+-5% 50V
C0218	0890046	CERAMIC DISC 0.1UF+80-20% 50V
C0219	0893031	CERAMIC CHIP 1000PF+-10% 50V
C0220	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C0221	0800112	ELECTROLYTIC 2.2UF 50V
C0222	0893039	CERAMIC CHIP 4700PF+-10% 50V
C0223	0800118	ELECTROLYTIC 4.7UF 35V
C0224	0890015	CERAMIC DISC 33PF+-50% 50V
C0225	0890026	CERAMIC DISC 220PF+-10% 50V
C0226	0890044	CERAMIC DISC 0.022UF+80-20% 25V
C0227	0800107	ELECTROLYTIC 0.47UF 50V
C0228	0893008	CERAMIC CHIP 0.1UF +-10% 16V
C0230	0893002	CERAMIC CHIP 0.033UF+-10% 16V
C0233	0800122	ELECTROLYTIC 10UF 16V
C0234	0800185	ELECTROLYTIC 47UF 6.3V
C0235	0893082	CERAMIC CHIP 0.022UF+80-20% 50V
C0236	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C0237	0893008	CERAMIC CHIP 0.1UF +-10% 16V
C0238	0800178	ELECTROLYTIC 4.7UF 35V
C0239	0800179	ELECTROLYTIC 10UF 16V
C0241	0893055	CERAMIC CHIP 0.1UF+80-20% 16V
C0242	0800178	ELECTROLYTIC 4.7UF 35V
C0243	0893008	CERAMIC CHIP 0.1UF +-10% 16V
C0244	0254455	ELECTROLYTIC 0.47UF+-20% 50V
C0245	0800177	ELECTROLYTIC 3.3UF 50V
C0246	0893008	CERAMIC CHIP 0.1UF +-10% 16V
C0247	0209936	CERAMIC CHIP 33PF+-5% 50V
C0249	0893008	CERAMIC CHIP 0.1UF +-10% 16V
C0251	0893008	CERAMIC CHIP 0.1UF +-10% 16V
C0252	0209944	CERAMIC CHIP 150PF+-5% 50V
C0254	0893055	CERAMIC CHIP 0.1UF+80-20% 16V
C0255	0893055	CERAMIC CHIP 0.1UF+80-20% 16V
C0256	0893055	CERAMIC CHIP 0.1UF+80-20% 16V
C0260	0209933	CERAMIC CHIP 18PF+-5% 50V
C0262	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C0263	0209931	CERAMIC CHIP 12PF+-5% 50V
C0264	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C0265	0893008	CERAMIC CHIP 0.1UF +-10% 16V
C0273	0209937	CERAMIC CHIP 39PF+-5% 50V
C0402	0800117	ELECTROLYTIC 4.7UF 25V
C0403	0893002	CERAMIC CHIP 0.033UF+-10% 16V
C0404	0893088	CERAMIC CHIP 0.015UF+-10% 16V
C0406	0893037	CERAMIC CHIP 3300PF+-10% 50V
C0407	0800122	ELECTROLYTIC 10UF 16V
C0408	0800122	ELECTROLYTIC 10UF 16V
C0409	0209906	CERAMIC DISC 820PF+-5% 50V
C0410	0893088	CERAMIC CHIP 0.015UF+-10% 16V
C0411	0800109	ELECTROLYTIC 1.0UF 50V
C0412	0800101	ELECTROLYTIC 0.1UF 50V
C0413	0800101	ELECTROLYTIC 0.1UF 50V
C0414	0800109	ELECTROLYTIC 1.0UF 50V
C0420	AN10332R	CAPACITOR 0.027UF+-5% 100V
C0421	0890026	CERAMIC DISC 220PF+-10% 50V
C0422	0800335	ELECTROLYTIC 220UF 16V
C0424	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C0427	0893037	CERAMIC CHIP 3300PF+-10% 50V
C0429	0890044	CERAMIC DISC 0.022UF+80-20% 25V
C0434	0800117	ELECTROLYTIC 4.7UF 25V
C0435	0893033	CERAMIC CHIP 1500PF+-10% 50V
C0437	0800009	ELECTROLYTIC 4.7UF 25V
C0501	0800297	ELECTROLYTIC 22UF 6.3V
C0502	0800287	CAPASITOR 4.7UF+-20% 35V
C0503	0800287	CAPASITOR 4.7UF+-20% 35V
C0504	0800118	ELECTROLYTIC 4.7UF 35V [FX623A]
C0506	0800308	ELECTROLYTIC 33UF 16V
C0507	0893004	CERAMIC CHIP 0.047UF+-10% 16V
C0508	0800112	ELECTROLYTIC 2.2UF 50V
C0509	0800143	ELECTROLYTIC 100UF 6.3V
C0510	0893088	CERAMIC CHIP 0.015UF+-10% 16V
C0511	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C0512	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C0513	0800139	ELECTROLYITC 47UF 10V
C0514	0893013	CERAMIC CHIP 0.22UF+-10% 16V
C0517	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C0518	0893088	CERAMIC CHIP 0.015UF+-10% 16V
C0519	0800143	ELECTROLYTIC 100UF 6.3V
C0520	0800112	ELECTROLYTIC 2.2UF 50V
C0521	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C0522	0893004	CERAMIC CHIP 0.047UF+-10% 16V
C0524	0800118	ELECTROLYTIC 4.7UF 35V [FX623A]
C0525	0800118	ELECTROLYTIC 4.7UF 35V
C0526	0800118	ELECTROLYTIC 4.7UF 35V
C0528	0880051	MYLAR 0.033UF+-10% 50V
C0529	0800122	ELECTROLYTIC 10UF 16V
C0530	0800291	ELECTROLYTIC 10UF 16V
C0531	0800291	ELECTROLYTIC 10UF 16V
C0532	0800317	ELECTROLYTIC 47UF 16V
C0533	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C0534	0800135	ELECTROLYTIC 33UF 16V
C0535	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C0601	0207453	ELECTROLYTIC 2.2UF 50V
C0602	0893013	CERAMIC CHIP 0.22UF+-10% 16V
C0605	0880055	MYLAR 0.068UF+-10% 50V
C0606	0893031	CERAMIC CHIP 1000PF+-10% 50V
C0607	0209938	CERAMIC CHIP 47PF+-5% 50V
C0608	0890022	CERAMIC DISC 100PF+-10% 50V
C0609	0800179	ELECTROLYTIC 10UF 16V
C0610	0800141	ELECTROLYTIC 47UF 16V
C0612	0800128	ELECTROLYTIC 22UF 16V
C0615	0800317	ELECTROLYTIC 47UF 16V
C0620	0890035	CERAMIC DISC 1000PF+-10% 50V
C0621	0890038	CERAMIC DISC 3300PF+-20% 16V
C0622	0893065	CERAMIC CHIP 0.047UF+80-20% 25V
C0623	0890043	CERAMIC DISC 0.01UF+-20% 16V
C0624	0890044	CERAMIC DISC 0.022UF+80-20% 25V
C0627	0890023	CERAMIC DISC 120PF+-10% 50V
△C0851	AN10201S	FILM CAPACITOR 0.1UF+-20% 250V
△C0859	0235992	CERAMIC DISC 2200PF 250V
△C0860	0235992	CERAMIC DISC 2200PF 250V
C0862	AL10192	ELECTROLYTIC 100UF 200V
C0865	AN10401R	CAPACITOR 0.047UF+-10% 250V
C0866	0880053	POLYESTER FILM 0.047UF+-10% 50V
C0867	0880039	POLYESTER FILM 0.0047UF+-10% 50V
C0868	0880035	POLYESTER FILM 0.0022UF+-10% 50V
C0870	0254403	CAPACITOR 22UF+-20% 50V
C0871	0254405	CAPACITOR 1000UF+-20% 25V
C0872	0800353	ELECTROLYTIC 470UF 16V

SYMBOL-NO	P-NO	DESCRIPTION
C0873	0254405	CAPACITOR 1000UF+-20% 25V [FX621A]
C0873	0254406	CAPACITOR 3300UF+-20% 10V [FX623A]
C0874	0800352	ELECTROLYTIC 470UF 10V
C0875	0880044	POLYESTER FILM 0.01UF+-10% 50V
C0876	0800308	ELECTROLYTIC 33UF 16V
C0877	1143002	CERAMIC DISC 100PF 500V
C0878	0890044	CERAMIC DISC 0.022UF+80-20% 25V
C0882	0800047	ELECTROLYTIC 100UF 6.3V
C0885	AJ10131R	CERAMIC CAPACITOR 470PF+-10% 500V
C0888	AJ10139R	CERAMIC CAPACITOR 3300PF+-10% 1KV[FX621A]
C0888	1143005	CERAMIC DISC 220PF+-5% 1KV [FX623A]
C0901	0893055	CERAMIC CHIP 0.1UF+80-20% 16V
C0902	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C0904	0217516	CAPACITOR 0.047UF+80-20% 5.5V
C0906	0800176	ELECTROLYTIC 2.2UF 50V
C0907	0209927	CERAMIC CHIP 7.0PF+-0.5% 50V
C0908	0209927	CERAMIC CHIP 7.0PF+-0.5% 50V
C0909	0209932	CERAMIC CHIP 15PF+-5% 50V
C0910	0209932	CERAMIC CHIP 15PF+-5% 50V
C0912	0893055	CERAMIC CHIP 0.1UF+80-20% 16V
C0913	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C0914	0800308	ELECTROLYTIC 33UF 16V
C0915	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C0916	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C0917	0800141	ELECTROLYTIC 47UF 16V
C0918	0893082	CERAMIC CHIP 0.022UF+80-20% 50V
C0919	0893065	CERAMIC CHIP 0.047UF+80-20% 25V
C0920	0209938	CERAMIC CHIP 47PF+-5% 50V
C0922	0893055	CERAMIC CHIP 0.1UF+80-20% 16V
C0923	0893082	CERAMIC CHIP 0.022UF+80-20% 50V
C0924	0209938	CERAMIC CHIP 47PF+-5% 50V
C0925	0209938	CERAMIC CHIP 47PF+-5% 50V
C0926	0209930	CERAMIC CHIP 10PF+-0.5% 50V
C0927	0209948	CERAMIC CHIP 330PF+-5% 50V
C0928	0893065	CERAMIC CHIP 0.047UF+80-20% 25V
C0940	0209943	CERAMIC DISC 120PF+-5% 50V
C0942	0890044	CERAMIC DISC 0.022UF+80-20% 25V
C0980	0890043	CERAMIC DISC 0.01UF+-20% 16V
C0981	0890043	CERAMIC DISC 0.01UF+-20% 16V
C0982	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C0985	0209904	CERAMIC DISC 560PF+-5% 50V
C1102	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C1103	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C1104	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C1105	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C1106	0800185	ELECTROLYTIC 47UF 6.3V
C1107	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C1108	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C1110	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C1111	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C1112	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C1114	0893091	CERAMIC CHIP 0.022UF+-10% 16V
C1115	0893091	CERAMIC CHIP 0.022UF+-10% 16V
C1116	0893091	CERAMIC CHIP 0.022UF+-10% 16V
C1117	0893091	CERAMIC CHIP 0.022UF+-10% 16V
C1118	0893091	CERAMIC CHIP 0.022UF+-10% 16V
C1119	0893091	CERAMIC CHIP 0.022UF+-10% 16V
C1120	0893091	CERAMIC CHIP 0.022UF+-10% 16V
C1121	0893091	CERAMIC CHIP 0.022UF+-10% 16V
C1122	0893091	CERAMIC CHIP 0.022UF+-10% 16V
C1123	0893091	CERAMIC CHIP 0.022UF+-10% 16V
C1124	0893031	CERAMIC CHIP 1000PF+-10% 50V
C1125	0800185	ELECTROLYTIC 47UF 6.3V
C1126	0893082	CERAMIC CHIP 0.022UF+80-20% 50V
C1127	0893013	CERAMIC CHIP 0.22UF+-10% 16V
C1128	0800185	ELECTROLYTIC 47UF 6.3V
C1129	0893082	CERAMIC CHIP 0.022UF+80-20% 50V
C1131	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C1134	0209930	CERAMIC CHIP 10PF+-0.5% 50V
C1135	0209930	CERAMIC CHIP 10PF+-0.5% 50V
C1136	0209930	CERAMIC CHIP 10PF+-0.5% 50V
C1137	0209935	CERAMIC CHIP 27PF+-5% 50V
C1138	0209943	CERAMIC DISC 120PF+-5% 50V
C1140	0209943	CERAMIC DISC 120PF+-5% 50V
C1141	0893031	CERAMIC CHIP 1000PF+-10% 50V
C1401	0890043	CERAMIC DISC 0.01UF+-20% 16V
C1402	0209943	CERAMIC DISC 120PF+-5% 50V
C1403	0800118	ELECTROLYTIC 4.7UF 35V
C1404	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C1405	0890043	CERAMIC DISC 0.01UF+-20% 16V
C1409	0209937	CERAMIC CHIP 39PF+-5% 50V
C1410	0209936	CERAMIC CHIP 33PF+-5% 50V
C1411	0209945	CERAMIC DISC 180PF+-5% 50V
C1414	0800122	ELECTROLYTIC 10UF 16V
C1415	0800118	ELECTROLYTIC 4.7UF 35V
C1416	0800317	ELECTROLYTIC 47UF 16V
C1417	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C1419	0209930	CERAMIC CHIP 10PF+-0.5% 50V
C1424	0890044	CERAMIC DISC 0.022UF+80-20% 25V
C1425	0209931	CERAMIC CHIP 12PF+-5% 50V
C1426	0893065	CERAMIC CHIP 0.047UF+80-20% 25V
C1427	0890039	CERAMIC DISC 4700PF+-20% 16V
C1701	0800185	ELECTROLYTIC 47UF 6.3V
C1702	08901O3	CERAMIC DISC 47000PF+80-20% 12V
C1703	08901O3	CERAMIC DISC 47000PF+80-20% 12V
C1704	08901O3	CERAMIC DISC 47000PF+80-20% 12V
C1705	0890035	CERAMIC DISC 1000PF+-10% 50V
C1706	0800185	ELECTROLYTIC 47UF 6.3V
C1802	0800103	ELECTROLYTIC 0.22UF 50V
C1811	0800317	ELECTROLYTIC 47UF 16V
C2101	0890035	CERAMIC DISC 1000PF+-10% 50V
C2102	0890044	CERAMIC DISC 0.022UF+80-20% 25V
C2501	0893037	CERAMIC CHIP 3300PF+-10% 50V
C2502	0893037	CERAMIC CHIP 3300PF+-10% 50V
C2503	0800352	ELECTROLYTIC 470UF 10V
C2504	0890043	CERAMIC DISC 0.01UF+-20% 16V [FX623A]
C2505	0800291	CAPACITOR 10UF+-20% 16V [FX623A]
C2506	0800291	CAPACITOR 10UF+-20% 16V [FX623A]
C2507	0800287	CAPASITOR 4.7UF+-20% 35V
C2508	0893037	CERAMIC CHIP 3300PF+-10% 50V
C2509	0800287	CAPASITOR 4.7UF+-20% 35V
C2513	0800317	ELECTROLYTIC 47UF 16V
C2514	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C2517	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C2518	0800044	ELECTROLYTIC 47UF 50V
C2519	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C2520	0800335	ELECTROLYTIC 220UF 16V
C2524	0893044	CERAMIC CHIP 0.01UF+-10% 50V
C2525	0800291	ELECTROLYTIC 10UF 16V
C2531	0800287	CAPASITOR 4.7UF+-20% 35V
C2532	0890044	CERAMIC DISC 0.022UF+80-20% 25V
C2539	0209849	CERAMIC CHIP 390PF+-5% 50V
C2901	0893031	CERAMIC CHIP 1000PF+-10% 50V [FX623A]
C2902	0800109	ELECTROLYTIC 1.0UF 50V [FX623A]
C2903	0893044	CERAMIC CHIP 0.01UF+-10% 50V [FX623A]
C2904	0800122	ELECTROLYTIC 10UF 16V [FX623A]
C2905	0893044	CERAMIC CHIP 0.01UF+-10% 50V [FX623A]
C2906	0800122	ELECTROLYTIC 10UF 16V [FX623A]
C2907	0800112	ELECTROLYTIC 2.2UF 50V [FX623A]
C2908	0890035	CERAMIC DISC 1000PF+-10% 50V [FX623A]

SYMBOL-NO	P-NO	DESCRIPTION
C2909	0209944	CERAMIC CHIP 150PF+-5% 50V [FX623A]
C2910	0209944	CERAMIC CHIP 150PF+-5% 50V [FX623A]
		RESISTORS
R0205	0103846	CHIP RESISTOR 1.8KOHM+-5% 0.1W
R0206	0103859	CHIP RESISTOR 22KOHM+-5% 0.1W
R0207	0103850	CHIP RESISTOR 3.9KOHM+-5% 0.1W
R0208	0103843	CHIP RESISTOR 1KOHM+-5% 0.1W
R0212	0700058	CARBON FILM 22KOHM+-5% 1/8W
R0213	0700058	CARBON FILM 22KOHM+-5% 1/8W
R0215	0700039	CARBON FILM 820 OHM+-5% 1/8W
R0216	0700045	CARBON FILM 2.2KOHM+-5% 1/8W
R0217	0700059	CARBON FILM 27KOHM+-5% 1/8W
R0218	0700027	CARBON FILM 100 OHM+-5% 1/8W
R0226	0103846	CHIP RESISTOR 1.8KOHM+-5% 0.1W
R0227	0103859	CHIP RESISTOR 22KOHM+-5% 0.1W
R0228	0103859	CHIP RESISTOR 22KOHM+-5% 0.1W
R0229	0700032	CARBON FILM 220 OHM+-5% 1/8W
R0240	0700043	CARBON FILM 1.5KOHM+-5% 1/8W
R0241	0700052	CARBON FILM 6.8KOHM+-5% 1/8W
R0253	0700038	CARBON FILM 680 OHM+-5% 1/8W
R0257	0700051	CARBON FILM 5.6KOHM+-5% 1/8W
R0258	0700027	CARBON FILM 100 OHM+-5% 1/8W
R0263	0101391	CARBON FILM 2.2MOHM+-5% 1/8W
R0402	0700059	CARBON FILM 27KOHM+-5% 1/8W
R0403	0103843	CHIP RESISTOR 1KOHM+-5% 0.1W
R0404	0103840	CHIP RESISTOR 560 OHM+-5% 0.1W
R0407	0103833	CHIP RESISTOR 150 OHM+-5% 0.1W
R0408	0700061	CARBON FILM 33KOHM+-5% 1/8W
R0409	0103871	CHIP RESISTOR 220KOHM+-5% 0.1W
R0410	0103851	CHIP RESISTOR 4.7KOHM+-5% 0.1W
R0420	0103859	CHIP RESISTOR 22KOHM+-5% 0.1W
R0421	0103859	CHIP RESISTOR 22KOHM+-5% 0.1W
R0422	0103819	CHIP RESISTOR 10 OHM+-5% 0.1W
R0423	0700057	CARBON FILM 18KOHM+-5% 1/8W
R0424	0103858	CHIP RESISTOR 18KOHM+-5% 0.1W
R0426	0700063	CARBON FILM 47KOHM+-5% 1/8W
R0427	0700045	CARBON FILM 2.2KOHM+-5% 1/8W
R0429	0700054	CARBON FILM 10KOHM+-5% 1/8W
R0430	0700058	CARBON FILM 22KOHM+-5% 1/8W
R0431	0700049	CARBON FILM 4.7KOHM+-5% 1/8W
R0432	0700049	CARBON FILM 4.7KOHM+-5% 1/8W
R0434	0700052	CARBON FILM 6.8KOHM+-5% 1/8W
R0437	0103879	CHIP RESISTOR 1MOHM+-5% 0.1W
R0501	0700054	CARBON FILM 10KOHM+-5% 1/8W
R0502	0700048	CARBON FILM 3.9KOHM+-5% 1/8W
R0503	0700063	CARBON FILM 47KOHM+-5% 1/8W
R0504	0700058	CARBON FILM 22KOHM+-5% 1/8W
R0505	0700063	CARBON FILM 47KOHM+-5% 1/8W [FX623A]
R0506	0700058	CARBON FILM 22KOHM+-5% 1/8W [FX623A]
R0509	0700049	CARBON FILM 4.7KOHM+-5% 1/8W
R0510	0104252	CHIP RESISTOR 510 OHM+-5% 1/10W
R0511	A010296R	CHIP RESISTOR 15KOHM+-0.1% 1/10W
R0516	0700049	CARBON FILM 4.7KOHM+-5% 1/8W
R0517	0104252	CHIP RESISTOR 510 OHM+-5% 1/10W
R0520	0700063	CARBON FILM 47KOHM+-5% 1/8W [FX623A]
R0521	0700058	CARBON FILM 22KOHM+-5% 1/8W [FX623A]
R0522	0103863	CHIP RESISTOR 47KOHM+-5% 0.1W
R0523	0103859	CHIP RESISTOR 22KOHM+-5% 0.1W
R0524	0700054	CARBON FILM 10KOHM+-5% 1/8W
R0525	0700048	CARBON FILM 3.9KOHM+-5% 1/8W
R0526	0103839	CHIP RESISTOR 470 OHM+-5% 0.1W
R0527	0103839	CHIP RESISTOR 470 OHM+-5% 0.1W
R0530	0103850	CHIP RESISTOR 3.9KOHM+-5% 0.1W
R0531	0103844	CHIP RESISTOR 1.2KOHM+-5% 0.1W
R0532	0103859	CHIP RESISTOR 22KOHM+-5% 0.1W
R0533	0103866	CHIP RESISTOR 82KOHM+-5% 0.1W
R0534	0103851	CHIP RESISTOR 4.7KOHM+-5% 0.1W
R0540	0700033	CARBON FILM 270 OHM+-5% 1/8W
R0541	0700033	CARBON FILM 270 OHM+-5% 1/8W
R0602	0700041	CARBON FILM 1.0KOHM+-5% 1/8W
R0605	0700049	CARBON FILM 4.7KOHM+-5% 1/8W
R0615	0700041	CARBON FILM 1.0KOHM+-5% 1/8W
R0621	0700041	CARBON FILM 1.0KOHM+-5% 1/8W
R0622	0700041	CARBON FILM 1.0KOHM+-5% 1/8W
R0623	0103859	CHIP RESISTOR 22KOHM+-5% 0.1W
R0624	0103855	CHIP RESISTOR 10KOHM+-5% 0.1W
R0625	0700041	CARBON FILM 1.0KOHM+-5% 1/8W
R0626	0700041	CARBON FILM 1.0KOHM+-5% 1/8W
R0627	0700036	CARBON FILM 470 OHM+-5% 1/8W
R0628	0103839	CHIP RESISTOR 470 OHM+-5% 0.1W
R0629	0103837	CHIP RESISTOR 330 OHM+-5% 0.1W
R0630	0103837	CHIP RESISTOR 330 OHM+-5% 0.1W
R0631	0103870	CHIP RESISTOR 18KOHM+-5% 0.1W
R0632	0103843	CHIP RESISTOR 1KOHM+-5% 0.1W
R0633	0103879	CHIP RESISTOR 1MOHM+-5% 0.1W
R0634	0700041	CARBON FILM 1.0KOHM+-5% 1/8W
R0635	0700041	CARBON FILM 1.0KOHM+-5% 1/8W
R0636	0700047	CARBON FILM 3.3KOHM+-5% 1/8W
R0638	0700048	CARBON FILM 3.9KOHM+-5% 1/8W
R0704	0700041	CARBON FILM 1.0KOHM+-5% 1/8W
R0705	0700039	CARBON FILM 820 OHM+-5% 1/8W
R0706	0700041	CARBON FILM 1.0KOHM+-5% 1/8W
R0707	0700041	CARBON FILM 1.0KOHM+-5% 1/8W
R0708	0700046	CARBON FILM 2.7KOHM+-5% 1/8W
R0709	0103833	CHIP RESISTOR 150 OHM+-5% 0.1W
R0710	0700054	CARBON FILM 10KOHM+-5% 1/8W [FX623A]
R0712	0700036	CARBON FILM 470 OHM+-5% 1/8W [FX623A]
R0714	0700023	CARBON FILM 47 OHM+-5% 1/8W [FX623A]
R0715	0700049	CARBON FILM 4.7KOHM+-5% 1/8W
R0716	0700047	CARBON FILM 3.3KOHM+-5% 1/8W
⚠R0851	AT10401G	RESISTOR 4.7MOHM+-10% 1/2W
R0853	0700081	CARBON FILM 1.0MOHM+-5% 1/8W
R0856	AT10246S	RESISTOR 0.33 OHM+-5% 1W
R0857	0700041	CARBON FILM 1.0KOHM+-5% 1/8W
R0859	0700032	CARBON FILM 220 OHM+-5% 1/8W
R0860	0116664	CHIP RESISTOR 68KOHM+-5% 2W
R0861	0116664	CHIP RESISTOR 68KOHM+-5% 2W
R0862	0700047	CARBON FILM 3.3KOHM+-5% 1/8W
R0863	0700055	CARBON FILM 12KOHM+-5% 1/8W
R0864	0700033	CARBON FILM 270 OHM+-5% 1/8W
R0865	0700038	CARBON FILM 680 OHM+-5% 1/8W
R0866	0700034	CARBON FILM 330 OHM+-5% 1/8W
R0867	0700038	CARBON FILM 680 OHM+-5% 1/8W
R0868	0700041	CARBON FILM 1.0KOHM+-5% 1/8W
R0869	0104114	CHIP RESISTOR 3.3KOHM+-1% 0.1W
R0871	0105572	METAL FILM RESISTOR 2.7KOHM+-1% 1/10
R0872	0700045	CARBON FILM 2.2KOHM+-5% 1/8W
R0873	0700045	CARBON FILM 2.2KOHM+-5% 1/8W
R0874	0700058	CARBON FILM 22KOHM+-5% 1/8W
R0875	0700032	CARBON FILM 220 OHM+-5% 1/8W
R0878	0103859	CHIP RESISTOR 22KOHM+-5% 0.1W
R0879	0700038	CARBON FILM 680 OHM+-5% 1/8W
R0880	0700032	CARBON FILM 220 OHM+-5% 1/8W
R0885	0700056	CARBON FILM 15KOHM+-5% 1/8W
R0886	0700056	CARBON FILM 15KOHM+-5% 1/8W
R0887	0700046	CARBON FILM 2.7KOHM+-5% 1/8W
R0889	0700062	CARBON FILM 39KOHM+-5% 1/8W
R0891	0700058	CARBON FILM 22KOHM+-5% 1/8W

SYMBOL-NO	P-NO	DESCRIPTION	
R0892	0103859	CHIP RESISTOR 22KOHM+-5% 0.1W	
R0893	0700058	CARBON FILM 22KOHM+-5% 1/8W	
R0894	0700058	CARBON FILM 22KOHM+-5% 1/8W	
R0901	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	
R0902	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	
R0903	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	[FX623A]
R0905	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	
R0906	0103843	CHIP RESISTOR 1KOHM+-5% 0.1W	
R0908	0700054	CARBON FILM 10KOHM+-5% 1/8W	
R0909	0700067	CARBON FILM 100KOHM+-5% 1/8W	
R0910	0700054	CARBON FILM 10KOHM+-5% 1/8W	
R0911	0700067	CARBON FILM 100KOHM+-5% 1/8W	
R0913	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	
R0914	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	
R0915	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	
R0916	0103843	CHIP RESISTOR 1KOHM+-5% 0.1W	
R0917	0103843	CHIP RESISTOR 1KOHM+-5% 0.1W	
R0918	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	
R0919	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	
R0920	0700054	CARBON FILM 10KOHM+-5% 1/8W	
R0923	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	[FX623A]
R0924	0103840	CHIP RESISTOR 560 OHM+-5% 0.1W	
R0925	0103840	CHIP RESISTOR 560 OHM+-5% 0.1W	
R0926	0103840	CHIP RESISTOR 560 OHM+-5% 0.1W	
R0927	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	
R0928	0103851	CHIP RESISTOR 4.7KOHM+-5% 0.1W	
R0929	0103851	CHIP RESISTOR 4.7KOHM+-5% 0.1W	
R0934	0700049	CARBON FILM 4.7KOHM+-5% 1/8W	
R0935	0700032	CARBON FILM 220 OHM+-5% 1/8W	
R0936	0700054	CARBON FILM 10KOHM+-5% 1/8W	
R0937	0700037	CARBON FILM 560 OHM+-5% 1/8W	
R0939	0103843	CHIP RESISTOR 1KOHM+-5% 0.1W	
R0940	0103839	CHIP RESISTOR 470 OHM+-5% 0.1W	
R0941	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	
R0943	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	
R0944	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	
R0945	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	
R0946	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	
R0947	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	
R0948	0700049	CARBON FILM 4.7KOHM+-5% 1/8W	
R0950	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	[FX623A]
R0951	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	
R0952	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	
R0954	0700073	CARBON FILM 270KOHM+-5% 1/8W	
R0955	0103839	CHIP RESISTOR 470 OHM+-5% 0.1W	
R0956	0700036	CARBON FILM 470 OHM+-5% 1/8W	
R0957	0103879	CHIP RESISTOR 1MOHM+-5% 0.1W	
R0963	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	[FX623A]
R0967	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	
R0969	0700027	CARBON FILM 100 OHM+-5% 1/8W	
R0970	0700027	CARBON FILM 100 OHM+-5% 1/8W	
R0971	0103843	CHIP RESISTOR 1KOHM+-5% 0.1W	
R0972	0103851	CHIP RESISTOR 4.7KOHM+-5% 0.1W	
R0976	0101725	CHIP RESISTOR 2.2 OHM+-5% 1/4W	
R0977	0700067	CARBON FILM 100KOHM+-5% 1/8W	
R0978	0104111	CHIP RESISTOR 10KOHM+-1% 1/10W	
R0979	0700052	CARBON FILM 6.8KOHM+-5% 1/8W	
R0980	0700058	CARBON FILM 22KOHM+-5% 1/8W	
R0981	0700054	CARBON FILM 10KOHM+-5% 1/8W	
R0987	0700054	CARBON FILM 10KOHM+-5% 1/8W	[FX621A]
R0988	0103854	CHIP RESISTOR 8.2KOHM+-5% 0.1W	
R0990	0700067	CARBON FILM 100KOHM+-5% 1/8W	
R0991	0103836	CHIP RESISTOR 270 OHM+-5% 0.1W	
R0992	0103836	CHIP RESISTOR 270 OHM+-5% 0.1W	
R0998	0103854	CHIP RESISTOR 8.2KOHM+-5% 0.1W	

SYMBOL-NO	P-NO	DESCRIPTION	
R0999	0700054	CARBON FILM 10KOHM+-5% 1/8W	
R1101	0103850	CHIP RESISTOR 3.9KOHM+-5% 0.1W	
R1103	0103843	CHIP RESISTOR 1KOHM+-5% 0.1W	
R1104	0103859	CHIP RESISTOR 22KOHM+-5% 0.1W	
R1107	0103839	CHIP RESISTOR 470 OHM+-5% 0.1W	
R1108	0103839	CHIP RESISTOR 470 OHM+-5% 0.1W	
R1109	0103860	CHIP RESISTOR 27KOHM+-5% 0.1W	
R1110	0103842	CHIP RESISTOR 820 OHM+-5% 0.1W	
R1112	0103843	CHIP RESISTOR 1KOHM+-5% 0.1W	
R1113	0103843	CHIP RESISTOR 1KOHM+-5% 0.1W	
R1115	0103836	CHIP RESISTOR 270 OHM+-5% 0.1W	
R1116	0103853	CHIP RESISTOR 6.8KOHM+-5% 0.1W	
R1117	0700054	CARBON FILM 10KOHM+-5% 1/8W	
R1118	0103835	CHIP RESISTOR 220 OHM+-5% 0.1W	
R1120	0103835	CHIP RESISTOR 220 OHM+-5% 0.1W	
R1121	0700032	CARBON FILM 220 OHM+-5% 1/8W	
R1403	0700045	CARBON FILM 2.2KOHM+-5% 1/8W	
R1405	0103843	CHIP RESISTOR 1KOHM+-5% 0.1W	
R1406	0103828	CHIP RESISTOR 56 OHM+-5% 0.1W	
R1407	0103837	CHIP RESISTOR 330 OHM+-5% 0.1W	
R1409	0103843	CHIP RESISTOR 1KOHM+-5% 0.1W	
R1410	0103846	CHIP RESISTOR 1.8KOHM+-5% 0.1W	
R1412	0700076	CARBON FILM 470KOHM+-5% 1/8W	
R1413	0103859	CHIP RESISTOR 22KOHM+-5% 0.1W	
R1416	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	
R1418	0700027	CARBON FILM 100 OHM+-5% 1/8W	
R1421	0700027	CARBON FILM 100 OHM+-5% 1/8W	
R1422	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	
R1423	0103835	CHIP RESISTOR 220 OHM+-5% 0.1W	
R1424	0700032	CARBON FILM 220 OHM+-5% 1/8W	
R1430	0700045	CARBON FILM 2.2KOHM+-5% 1/8W	
R1433	0103849	CHIP RESISTOR 3.3KOHM+-5% 0.1W	
R1434	0103879	CHIP RESISTOR 1MOHM+-5% 0.1W	
R1438	0103843	CHIP RESISTOR 1KOHM+-5% 0.1W	
R1701	0700054	CARBON FILM 10KOHM+-5% 1/8W	
R1702	0700063	CARBON FILM 47KOHM+-5% 1/8W	
R1703	0700032	CARBON FILM 220 OHM+-5% 1/8W	[FX621A]
R1703	0700039	CARBON FILM 820 OHM+-5% 1/8W	[FX623A]
R1704	0700032	CARBON FILM 220 OHM+-5% 1/8W	[FX621A]
R1704	0700039	CARBON FILM 820 OHM+-5% 1/8W	[FX623A]
R1708	0700049	CARBON FILM 4.7KOHM+-5% 1/8W	[FX623A]
R1709	0700038	CARBON FILM 680 OHM+-5% 1/8W	[FX621A]
R1710	0700038	CARBON FILM 680 OHM+-5% 1/8W	[FX621A]
R1711	0700049	CARBON FILM 4.7KOHM+-5% 1/8W	
R1712	0700049	CARBON FILM 4.7KOHM+-5% 1/8W	
R1713	0700049	CARBON FILM 4.7KOHM+-5% 1/8W	
R1714	0700049	CARBON FILM 4.7KOHM+-5% 1/8W	
R1802	0700052	CARBON FILM 6.8KOHM+-5% 1/8W	
R1806	0700054	CARBON FILM 10KOHM+-5% 1/8W	
R1807	0700054	CARBON FILM 10KOHM+-5% 1/8W	
R1808	0700053	CARBON FILM 8.2KOHM+-5% 1/8W	
R1809	0700057	CARBON FILM 18KOHM+-5% 1/8W	
R1818	0700054	CARBON FILM 10KOHM+-5% 1/8W	
R1820	0700054	CARBON FILM 10KOHM+-5% 1/8W	
R1822	0700054	CARBON FILM 10KOHM+-5% 1/8W	
R2101	0700059	CARBON FILM 27KOHM+-5% 1/8W	
R2102	0700067	CARBON FILM 100KOHM+-5% 1/8W	
R2103	0103863	CHIP RESISTOR 47KOHM+-5% 0.1W	
R2104	0700032	CARBON FILM 220 OHM+-5% 1/8W	
R2105	0700063	CARBON FILM 47KOHM+-5% 1/8W	
R2106	0103893	CHIP RESISTOR 75 OHM+-5% 1/8W	
R2107	0700045	CARBON FILM 2.2KOHM+-5% 1/8W	
R2108	0700048	CARBON FILM 3.9KOHM+-5% 1/8W	
R2109	0700045	CARBON FILM 2.2KOHM+-5% 1/8W	
R2110	0700048	CARBON FILM 3.9KOHM+-5% 1/8W	

SYMBOL-NO	P-NO	DESCRIPTION	
R2111	0700045	CARBON FILM 2.2KOHM+-5% 1/8W	
R2112	0700045	CARBON FILM 2.2KOHM+-5% 1/8W	
R2113	0103893	CHIP RESISTOR 75 OHM+-5% 1/8W	
R2114	0103835	CHIP RESISTOR 220 OHM+-5% 0.1W	
R2115	0103855	CHIP RESISTOR 10KOHM+-5% 0.1W	
R2116	0700054	CARBON FILM 10KOHM+-5% 1/8W	
R2117	0700058	CARBON FILM 22KOHM+-5% 1/8W	
R2501	0700041	CARBON FILM 1.0KOHM+-5% 1/8W	
R2502	0103843	CHIP RESISTOR 1KOHM+-5% 0.1W	
R2503	0101400	CARBON FILM 750HM+-5% 1/8W	
R2504	0101400	CARBON FILM 750HM+-5% 1/8W	
R2507	0103849	CHIP RESISTOR 3.3KOHM+-5% 0.1W	
R2508	0103863	CHIP RESISTOR 47KOHM+-5% 0.1W	
R2509	0103849	CHIP RESISTOR 3.3KOHM+-5% 0.1W	
R2510	0103863	CHIP RESISTOR 47KOHM+-5% 0.1W	
R2511	0103849	CHIP RESISTOR 3.3KOHM+-5% 0.1W	
R2512	0103850	CHIP RESISTOR 3.9KOHM+-5% 0.1W	
R2514	0101835	CARBON FILM 1.5KOHM+-5% 1/4W	
R2515	0103871	CHIP RESISTOR 220KOHM+-5% 0.1W	
R2517	0103870	CHIP RESISTOR 180KOHM+-5% 0.1W	
R2518	0103855	CHIP RESISTOR 10KOHM+-5% 0.1W	
R2523	0103855	CHIP RESISTOR 10KOHM+-5% 0.1W	
R2524	0103849	CHIP RESISTOR 3.3KOHM+-5% 0.1W	
R2527	0700063	CARBON FILM 47KOHM+-5% 1/8W	
R2530	0101400	CARBON FILM 750HM+-5% 1/8W	[FX623A]
R2533	0103839	CHIP RESISTOR 470 OHM+-5% 0.1W	
R2534	0103839	CHIP RESISTOR 470 OHM+-5% 0.1W	
R2542	0700054	CARBON FILM 10KOHM+-5% 1/8W	
R2901	0700041	CARBON FILM 1KOHM+-5% 1/8W	[FX623A]
R2902	0700032	CARBON FILM 220 OHM+-5% 1/8W	[FX623A]
R2903	0103835	CHIP RESISTOR 220 OHM+-5% 0.1W	[FX623A]
R2904	0103855	CHIP RESISTOR 10KOHM+-5% 0.1W	[FX623A]
R2905	0700081	CARBON FILM 1.0MOHM+-5% 1/8W	[FX623A]
R2906	0700047	CARBON FILM 3.3KOHM+-5% 1/8W	[FX623A]
R2907	0103831	CHIP RESISTOR 100 OHM+-5% 0.1W	[FX623A]
R2908	0700027	CARBON FILM 100 OHM+-5% 1/8W	[FX623A]
R2909	0103855	CHIP RESISTOR 10KOHM+-5% 0.1W	[FX623A]
RF0861	BZ10471R	CORE	
RT1801	AW10188R	SEMI VARIABLE 22KOHM	

SEMI-CONDUCTORS

D0206	5339071	DIODE 1SS119	
⚠D0851	5336552	DIODE S1WBA60	
D0852	CH10191M	DIODE EG01C-T	
D0856	CH10921M	DIODE PR1003L	
D0857	CH10912F	DIODE UF3003-F	
D0858	CH10942F	DIODE SB360-F	[FX623A]
D0859	5339241	DIODE EK14	[FX621A]
D0860	CH10891M	DIODE 1N5817	
D0861	CH10891M	DIODE 1N5817	
D0864	CH10191M	DIODE EG01C-T	
D0901	CH10891M	DIODE 1N5817	
D0906	5339071	DIODE 1SS119	
D0908	CH10871M	DIODE 1N4001	
D0909	CH10871M	DIODE 1N4001	
D1101	5339071	DIODE 1SS119	
D1102	5339071	DIODE 1SS119	
D1403	5339071	DIODE 1SS119	
D1701	5339071	DIODE 1SS119	
D2501	5339071	DIODE 1SS119	
D2502	5339071	DIODE 1SS119	
D2504	5339071	DIODE 1SS119	
LD1701	CH10781R	DIODE SLP3117E	
LD1702	CH10781R	DIODE SLP3117E	
LD1703	CH10781R	DIODE SLP3117E	
LD1704	CH10781R	DIODE SLP3117E	
LD2101	CH10542	DIODE GL451L1	
LD2702	CH10791	DIODE SLR932C-20	[FX623A]
IC0201	CK14413U	IC HA118204F	
IC0202	CK13574R	IC MSM7476-76MS-KR1	
IC0501	CK16761	IC AN3962FB	
IC0851	CP11961R	IC HA17431PA	
IC0901	CK16738	IC HD6433977SB46F	
IC0902	CP10312R	IC PST9129	
IC0903	CP10914	IC ST24C01FB6	[FX621A]
IC0903	CP10915	IC ST24C02 6	[FX623A]
IC0904	CP10291	IC BA6209	
IC0905	CP11361R	IC M5278L05	
IC1101	CK14481	IC HA118198FP	
IC1102	CP11191	IC LA7256	
IC1701	CZ10181	IC BU9716K	
IC1801	CS10352	MODULE HTS7337A	
IC2101	CJ10212	PHOTO INTERLAPTER SG-236	
IC2102	CJ10222	PHOTO INTERLAPTER SG-237	
IC2501	CP11991	IC NJM2533D	[FX623A]
IC2901	CP11001	IC LC7455A	[FX623A]
Q0228	5326903	TRANSISTOR UN2213	
Q0406	5323172	TRANSISTOR 2SC1214CD	
Q0409	5327063	TRANSISTOR 2SC1740S	
Q0410	5326903	TRANSISTOR UN2213	
Q0411	5327021	TRANSISTOR 2SA844CD	
Q0412	5327063	TRANSISTOR 2SC1740S	
Q0413	5327063	TRANSISTOR 2SC1740S	
Q0701	1320004	TRANSISTOR 2SA854S0	[FX623A]
Q0702	5327073	TRANSISTOR DTC144ES	[FX623A]
Q0851	CF10622	TRANSISTOR FS3KM-10T0-220	
Q0852	CF10451R	TRANSISTOR 2SC3246	
Q0853	1321341	TRANSISTOR 2SD1765	
Q0854	5327131	TRANSISTOR 2SB562C	[FX621A]
Q0854	5327262	TRANSISTOR 2SB1326	[FX623A]
Q0855	CA10672R	TRANSISTOR 2SD601A	
Q0858	5327131	TRANSISTOR 2SB562C	
Q0859	5327063	TRANSISTOR 2SC1740S	
Q0864	1321341	TRANSISTOR 2SD1765	
Q0901	5327151	TRANSISTOR 2SA952	[FX623A]
Q0902	5327073	TRANSISTOR DTC144ES	
Q0905	CA10582R	TRANSISTOR 2SB709A	
Q0906	CA10582R	TRANSISTOR 2SB709A	
Q0912	5326903	TRANSISTOR UN2213	
Q0913	5326903	TRANSISTOR UN2213	
Q0914	5326903	TRANSISTOR UN2213	
Q1101	CA10672R	TRANSISTOR 2SD601A	
Q1102	CA10582R	TRANSISTOR 2SB709A	
Q1401	CA10672R	TRANSISTOR 2SD601A	
Q1404	CA10582R	TRANSISTOR 2SB709A	
Q1407	CA10582R	TRANSISTOR 2SB709A	
Q1409	CA10672R	TRANSISTOR 2SD601A	
Q1410	CA10582R	TRANSISTOR 2SB709A	
Q1411	CA10672R	TRANSISTOR 2SD601A	
Q1701	5327071	TRANSISTOR DTC124ES	
Q1702	5327071	TRANSISTOR DTC124ES	
Q1802	5327073	TRANSISTOR DTC144ES	
Q2101	CF10372	TRANSISTOR PT493FL1	
Q2102	CF10372	TRANSISTOR PT493FL1	
Q2103	5326903	TRANSISTOR UN2213	
Q2104	5326903	TRANSISTOR UN2213	
Q2501	CA10672R	TRANSISTOR 2SD601A	
Q2502	CA10672R	TRANSISTOR 2SD601A	
Q2503	CA10672R	TRANSISTOR 2SD601A	

SYMBOL-NO	P-NO	DESCRIPTION	
02504	5326903	TRANSISTOR UN2213	
02505	CA10672R	TRANSISTOR 2SD601A	
02506	5326903	TRANSISTOR UN2213	
02509	5327074	TRANSISTOR DTA144ES-T	
02901	CA10672R	TRANSISTOR 2SD601A	[FX623A]
⚠PC0851	5327593	PHOTO COUPLER PS2501-1	
⚠OF0851	5721945	IC PROTECTOR, ICP-N38	
⚠OF0852	5721946	PROTECTOR, ICP-N15	
ZD0851	5339251	DIODE HZS2-C3	
ZD0861	CH10961M	ZUNER DIODE MA7180-A	
ZD0862	5339268	DIODE HZS11B2	
ZD0864	5339482	DIODE HZS15-2	
ZD0901	5339275	DIODE HZS7-B2	
ZD0903	5339297	DIODE HZS5C3	
ZD0904	5339297	DIODE HZS5C3	
ZD2501	5339288	DIODE HZS30-3	
ZD2502	5339257	DIODE HZS4-B1	
		TRANSFORMERS	
T0401	BT10251	TRANSFORMER, POWER	
⚠T0851	BT10321	TRANSFORMER, POWER (HEPM)	
		COILS	
L0202	0770057	CHOKE COIL 100UH±5%	
L0203	5121288	COIL 15UH	
L0204	5121287	COIL 10UH	
L0205	0770057	CHOKE COIL 100UH±5%	
L0206	5121569	COIL 82UH	
L0208	0770057	CHOKE COIL 100UH±5%	
L0209	5159142	CHOKE COIL 12UH	
L0210	5159146	CHOKE COIL 27UH	
L0401	5159114	COIL 15UH	
L0403	0770057	CHOKE COIL 100UH±5%	
L0501	0770057	CHOKE COIL 100UH±5%	
L0502	0770057	CHOKE COIL 100UH±5%	
⚠L0851	BJ10251	FILTER, LC	
L0853	BH10337R	COIL 10UH	
L0854	BH10339R	COIL 22UH	
L1101	0770057	CHOKE COIL 100UH±5%	
L1102	5121611	COIL	
L1103	5121611	COIL	
L1105	5121296	COIL 220UH	
L1106	5159155	CHOKE COIL 120UH±10%	
L1402	5121288	COIL 15UH	
L1403	5121284	COIL 3.3UH	
L1406	0770057	CHOKE COIL 100UH±5%	
L1701	0770057	CHOKE COIL 100UH±5%	
L1801	0770057	CHOKE COIL 100UH±5%	
L2502	0770061	CHOKE COIL 180 UH	
L2504	0770057	CHOKE COIL 100UH±5%	
L2902	5121294	COIL 100UH	[FX623A]
L2903	5121294	COIL 100UH	[FX623A]
		CRYSTALS	
X0201	BP10611	CRYSTAL	
X0901	BP10571	CRYSTAL	
X0902	BP10251	CRYSTAL	
X2901	BP10461	CRYSTAL [FX623A]	
		MISCELLANEOUS	
BL0851	BZ10471R	CORE	

SYMBOL-NO	P-NO	DESCRIPTION	
BL0853	BZ10471R	CORE	
BL0901	BZ10471R	CORE	
BL0902	5274521	CORE, FERRITE	
⚠F0851	FN10201	FUSE 003A	
FE2501	5582218	TUNER IF UNIT (HEPM)	
⚠FH0851	5722412	HOLDER, FUSE	
⚠FH0852	5722412	HOLDER, FUSE	
IR1701	CW10173	MODULE TFMS5380B	
JK2501	ES10343	JACK	
JK2503	ES10343	JACK	[FX623A]
LCD1701	DB10341	FLOURESENT DISPLAY	
LMP1701	5763358	BACK LIGHT(HEPM)	[FX623A]
LMP1702	5763358	BACK LIGHT(HEPM)	[FX623A]
LMP1703	5763358	BACK LIGHT(HEPM)	[FX623A]
S0701	FE10141R	SWITCH	
S0702	FE10141R	SWITCH	
S0703	FE10141R	SWITCH	
S0704	FE10141R	SWITCH	
S0705	FE10141R	SWITCH	
S0706	FE10141R	SWITCH	
S0707	FE10141R	SWITCH	
S0708	5636101	SWITCH	
S1701	5634884	SWITCH	
S2101	FD10211	SWITCH, MODE	
S2102	5635631	SWITCH	
S2103	5635631	SWITCH	

CHAPTER 6 SCHEMATIC AND CIRCUIT BOARD DIAGRAMS

Applied Models: VT-FX621A VT-FX623A

Cautions when using schematic diagrams

Caution for safety
The parts marked ⚠ are critical for safety. Be sure to use the specified parts to ensure safety when replacing them.

1. Values in schematic diagrams
The values, dielectric strength (power capacitance) and tolerances of the resistors (excluding variable resistors) and capacitors are indicated in the schematic diagrams using abbreviations.

[Resistors]

Item	Indication
Value	No indication ····· Ω K ····· kΩ M ····· MΩ
Tolerance	No indication ····· ±5% (All tolerances other than ±5% are indicated in the schematic diagrams)
Power capacitance	No indication ····· 1/8W (1/16W for leadless resistors without indication) All capacitances other than the above are indicated in the schematic diagrams.

[Capacitors]

Item	Indication
Value	No indication ····· μF P ····· pF
Dielectric strengh	No indication ····· 50V (All dielectric strengths other than 50V are indicated in the schematic diagrams.)

[Coils]

Item	Indication
Value	μ ····· μH m ····· mH

2. Markings in schematic diagrams
(1) Parts marked "■" with circuit numbers in the schematic diagrams are discrete parts.
(2) Parts marked "●" with circuit numbers in the schematic diagrams are leadless parts.

Cautions when using circuit board diagrams

1. Identifications of sides A/B in circuit board diagrams
(1) Board having a pattern on one side and parts on both sides.
Side A: Shows discrete parts, viewed from the pattern side.
Side B: Shows leadless parts, viewed from the pattern side.
(2) Board having patterns on both sides and parts on both sides.
Side A: Shows parts and patterns which can be seen when the case is opened.
Side B: Shows parts and the pattern on the back of side A.

2. Table for indexing locations of parts
This table shows locations of each part on the circuit board diagrams. The locations are indicated using the guide scales on the external lines of diagrams.

(1) In case of one-layer board



(2) In case of side A/B indication board



CONNECTION DIAGRAM



6-1 CONNECTION

LCD DISPLAY (LCD) SCHEMATIC DIAGRAM



LCD DISPLAY [LCD]

LCD GRID TABLE



PIN No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30
COM1	Index	OFF	2d	Pf	2c	3e	3g	3d	3c	4e	4d	5e	5j	5d	6e	6d	6c	7d	CH	7c	8d	8j	8c	9d	9g	9c	—	COM	—	—
COM2	1g	1bc	2e	2f	2b	3f	3hj	3k	3b	4f	4c	5f	5g	5c	6f	6g	6b	7e	7g	7b	8e	8g	8b	9e	P5	9b	—	—	COM	—
COM3	ON	2a	2f	AM	COL1	—	3a	—	4f	4a	4b	COL2	5a	5b	6a	REM	VCR	7f	⊿	7a	8f	8a	L	9f	9a	R	REC	—	—	COM



6-2 LCD DISPLAY

6-3 LCD GRID TABLE

CYL. MOTOR DRIVE SCHEMATIC DIAGRAM



CAPSTAN MOTOR SCHEMATIC DIAGRAM



MECHANISM SENSOR [MAS] SCHEMATIC DIAGRAM



SERVO WAVEFORMS

1-A IC901-24 5.6Vp-p
2V/5.0msec. cm
REC/PLAY



2-A IC901-31 5.7Vp-p
2V/10.0msec. cm
REC



3-A IC901-32 5.7Vp-p
2V/10.0msec. cm
REC



4-B IC901-37 3.2Vp-p
1V/10.0msec. cm
PLAY



5-A IC901-38 4.6Vp-p
2V/500 μ sec. cm
REC/PLAY



6-A IC901-39 4.8Vp-p
2V/10.0msec. cm
REC/PLAY



1 2 3 4 5 6 7 8

CYL. MOTOR DRIVE, CAPSTAN MOTOR 6-4 6-5 MECHANISM SENSOR, SERVO WAVEFORMS

MAIN CONTROL [MAS] . LED [LED] SCHEMATIC DIAGRAMS



MAIN CONTROL 6-6 6-7 MAIN CONTROL. LED

MTS/JACK [MAS] SCHEMATIC DIAGRAM



PRE AMP/FM AUDIO [MAS] SCHEMATIC DIAGRAM



MEMO

LUMA/CHROMA WAVEFORMS

1-B IC201-4 550mVp-p 0.2V/5.0msec. cm PLAY	5-A IC201-13 530mVp-p 0.2V/20.0 μ sec. cm REC	9-B IC201-50 540mVp-p 0.2V/20.0 μ sec. cm PLAY	13-A IC201-61 1.4Vp-p 0.5V/20.0 μ sec. cm REC
			
2-A IC201-6 380mVp-p 0.2V/5.0msec. cm REC	5-B IC201-13 640mVp-p 0.2V/20.0 μ sec. cm PLAY	10-A IC201-53 5.0Vp-p 2V/20.0 μ sec. cm REC/PLAY	14-A IC201-63 680mVp-p 0.2V/20.0 μ sec. cm REC
			
3-B IC201-7 650mVp-p 0.2V/5.0msec. cm PLAY	6-A IC201-15 400mVp-p 0.1V/20.0 μ sec. cm REC	11-B IC201-55 500mVp-p 0.1V/20.0 μ sec. cm PLAY	14-B IC201-63 680mVp-p 0.2V/20.0 μ sec. cm PLAY
			
4-A IC201-11 330mVp-p 0.1V/20.0 μ sec. cm REC	7-A IC201-16 5.7Vp-p 2V/5.0msec. cm REC/PLAY	12-A IC201-57 2.1Vp-p 0.5V/20.0 μ sec. cm REC	15-A IC201-68 430mVp-p 0.2V/20.0 μ sec. cm REC
			
4-B IC201-11 420mVp-p 0.1V/20.0 μ sec. cm PLAY	8-A IC201-24 510mVp-p 0.2V/100nsec. cm REC/PLAY	12-B IC201-57 2.2Vp-p 0.5V/20.0 μ sec. cm PLAY	15-B IC201-68 430mVp-p 0.2V/20.0 μ sec. cm PLAY
			

LUMA/CHROMA. LINEAR AUDIO [MAS] SCHEMATIC DIAGRAM



LUMA/CHROMA. LINEAR AUDIO 6-14 6-15 LUMA/CHROMA. LINEAR AUDIO

SWITCHING REGULATOR [MAS] SCHEMATIC DIAGRAM



LCD. LED CIRCUIT BOARDS



LCD(LCD DISPLAY)
[PATTERN No.JK1165-4]



LED(LED)
[PATTERN No.JA1376-3]

LCD [LCD DIPLAY]
DIFFERENCE TABLE

NOTE: This table listes the different components marked with asterisks(*) in the circuit board diagrams.

SYMBOL-No.	FX621A	FX623A
JP1701	×	○
JP1702	○	×
JP1703	○	×
JP1704	×	○
LMP1701	×	○
LMP1702	×	○
LMP1703	×	○
R1708	×	○
R1709	○	×
R1710	○	×

IDENTIFICATION OF PARTS LOCATION

LCD [LCD DISPLAY]

Symbol No.	Parts Location
C	
C1701	1A
C1702	1A
C1703	1A
C1704	1A
C1705	1A
C1706	1A
D	
D1701	1A
IC	
IC1701	1A
IR	
IR1701	1A
JP	
JP1701	3A
JP1702	3A
JP1703	3A
JP1704	4A
L	
L1701	2A
LCD	
LCD1701	3A
LD	
LD1701	2A
LD1702	3A
LD1703	3A
LD1704	4A
LMP	
LMP1701	2A
LMP1702	3A
LMP1703	4A
PG	
PG1702	4A
PG1703	1A
Q	
Q1701	3A
Q1702	3A
R	
R1701	1A
R1702	1A
R1703	3A
R1704	2A
R1708	4A
R1709	3A
R1710	4A
R1711	1A
R1712	1A
R1713	1A
R1714	4A
S	
S1701	1A

MAS CIRCUIT BOARD[SIDE A]



MAS(MAIN)-SIDE A-
[PATTERN No.JA1376-3]

MAIN [MAS] – SIDE A – DIFFERENCE TABLE

NOTE: This table listes the different components marked with asterisks(∗) in the circuit board diagrams.

SYMBOL-No.	FX621A	FX623A
C0504	×	○
C0524	×	○
C2504	×	○
C2505	×	○
C2506	×	○
C2902	×	○
C2904	×	○
C2906	×	○
C2907	×	○
C2908	×	○
D0858	×	○
D0859	○	×
IC2501	×	○
IC2901	×	○
JK2503	×	○
JP0904	○	×
JP2510	○	×
K007	×	○
K013	×	○
K016	×	○
K048	×	○
K062	×	○
K068	×	○
K075	×	○
K102	×	○
K118	×	○
K158	×	○
K175	×	○
K177	×	○
K217	×	○
K236	○	×
K242	×	○
K266	×	○
K277	×	○

NOTE: This table listes the different components marked with asterisks(∗) in the circuit board diagrams.

SYMBOL-No.	FX621A	FX623A
K282	×	○
K293	×	○
K376	×	○
L2902	×	○
L2903	×	○
PG0704	×	○
Q0701	×	○
Q0702	×	○
Q0901	×	○
Q0902	×	○
R0505	×	○
R0506	×	○
R0520	×	○
R0521	×	○
R0710	×	○
R0711	×	JUMPER
R0712	×	○
R0714	×	○
R0903	×	○
R0907	×	JUMPER
R0923	×	○
R0936	×	○
R0937	×	○
R0950	×	○
R0963	×	○
R0987	○	×
R2530	×	○
R2901	×	○
R2902	×	○
R2905	×	○
R2906	×	○
R2908	×	○
X2901	×	○

IDENTIFICATION OF PARTS LOCATION

MAS [MAIN] 1/2

Symbol No.	Parts Location
BL	
BL0851	A-3H
BL0853	A-3H
BL0901	A-4F
BL0902	A-5E
C	
C0201	B-3E
C0204	B-3F
C0205	B-3F
C0208	B-3D
C0209	B-3E
C0211	A-3D
C0212	B-3E
C0213	A-3E
C0214	B-2F
C0215	A-3G
C0216	B-2F
C0218	A-2E
C0219	B-2F
C0220	B-3F
C0221	A-4E
C0222	B-4E
C0223	A-4E
C0224	A-4E
C0225	A-4E
C0226	A-3D
C0227	A-3D
C0228	B-3D
C0230	B-3D
C0233	A-3D
C0234	A-3E
C0235	B-3D
C0236	B-3E
C0237	B-2E
C0238	A-2E
C0239	A-2A
C0241	B-2E
C0242	A-3E
C0243	B-3E
C0244	A-3E
C0245	A-3E
C0246	B-3E
C0247	B-3E
C0249	B-3E
C0251	B-3E
C0252	B-3E
C0254	B-3E
C0255	B-3E
C0256	B-3E
C0260	B-3E
C0262	B-2C
C0263	B-3F
C0264	B-3F
C0265	B-2F
C0273	B-3D
C0402	A-3D
C0403	B-3D
C0404	B-3D
C0406	B-3D
C0407	A-3D
C0408	A-3D
C0409	B-3D
C0410	B-3D
C0411	A-3D
C0412	A-3D
C0413	A-3D
C0414	A-3D
C0420	A-1F
C0421	A-1F
C0422	A-1F
C0424	B-2F
C0427	B-2F
C0429	A-3D
C0434	A-3C
C0435	B-3D
C0437	A-1F
C0501	A-3A
C0502	A-3B
C0503	A-3B
C0504	A-3B
C0506	A-3B
C0507	B-3B
C0508	A-3B
C0509	A-3B
C0510	B-3B
C0511	B-3B
C0512	B-3C
C0513	A-3C
C0514	B-3B
C0517	B-3B
C0518	B-3C
C0519	A-3C
C0520	A-3C
C0521	B-3C
C0522	B-4B
C0524	A-4B
C0525	A-4C
C0526	A-4C
C0528	A-4B
C0529	A-3B
C0530	A-3B
C0531	A-3B
C0532	A-3B
C0533	B-3B
C0534	A-3B
C0535	B-4B
C0601	A-1E
C0602	B-1E
C0605	A-1E
C0606	B-5E
C0607	B-5D
C0608	A-5E
C0609	A-5D
C0610	A-5D
C0612	A-5D
C0615	A-1E
C0620	A-5D
C0621	A-5D
C0622	B-5E
C0623	A-5D
C0624	A-5D
C0627	A-5E
C0851	A-1H
C0859	A-2H
C0860	A-2H
C0862	A-2H
C0865	A-3H
C0866	A-2H
C0867	A-3H
C0868	A-3H
C0870	A-4I
C0871	A-5H
C0872	A-5H
C0873	A-4H
C0874	A-5H
C0875	A-4G
C0876	A-6I
C0877	A-4H
C0878	A-5H
C0882	A-6H
C0885	A-4H
C0888	A-3H
C0901	B-5E
C0902	B-6A
C0904	A-5A
C0906	A-6G
C0907	B-4F
C0908	B-4F
C0909	B-4F
C0910	B-4F
C0912	B-6H
C0913	B-6H
C0914	A-6I
C0915	B-6I
C0916	B-6I
C0917	A-6C
C0918	B-6F
C0919	B-5E
C0920	B-6F
C0922	B-6I
C0923	B-5D
C0924	B-6E
C0925	B-6E
C0926	B-6E
C0927	B-6F
C0928	B-6G
C0940	B-6E
C0942	A-5E
C0980	A-5G
C0981	A-5G
C0982	B-6D
C0985	B-5D
C1102	B-2D
C1103	B-2D
C1104	B-2D
C1105	B-1D
C1106	A-1D
C1107	B-1D
C1108	B-1D
C1110	B-1D
C1111	B-1D
C1112	B-1D
C1114	B-1C
C1115	B-1C
C1116	B-1C
C1117	B-1C
C1118	B-1C
C1119	B-1C
C1120	B-1C
C1121	B-1C
C1122	B-1C
C1123	B-1D
C1124	B-2D
C1125	A-2C
C1126	B-2C
C1127	B-2C
C1128	A-2C
C1129	B-2C
C1131	B-2C
C1134	B-1D
C1135	B-1D
C1136	B-1D
C1137	B-2C
C1138	B-2D
C1140	B-2C
C1141	B-2D
C1401	A-4F
C1402	B-4F
C1403	A-4D
C1404	B-4E
C1405	A-4F
C1409	B-4E
C1410	B-4E
C1411	B-4E
C1414	A-4D
C1415	A-4D
C1416	A-2A
C1417	B-2A
C1419	B-1A
C1424	A-4D
C1425	B-2F
C1426	B-4F
C1427	A-4D
C1802	A-4A
C1811	A-4A
C2101	A-4G
C2102	A-4B
C2501	B-1C
C2502	B-1B
C2503	A-1A
C2504	A-2B
C2505	A-1B
C2506	A-1B
C2507	A-2A
C2508	B-1B
C2509	A-2A
C2513	A-2A
C2514	B-2A
C2517	B-2A
C2518	A-2A
C2519	B-3A
C2520	A-3A
C2524	B-3A
C2525	A-3A
C2531	A-3A
C2532	A-3A
C2539	B-1A
C2901	B-2B
C2902	A-2C
C2903	B-2B
C2904	A-2B
C2905	B-2B
C2906	A-1C
C2907	A-2B
C2908	A-2B
C2909	B-2B
C2910	B-2B
D	
D0206	A-3E
D0851	A-2H
D0852	A-3H
D0856	A-4I
D0857	A-4H
D0858	A-4H
D0859	A-4H
D0860	A-5G
D0861	A-5G
D0864	A-3I
D0901	A-6A
D0906	A-5G
D0908	A-6H
D0909	A-6H
D1101	A-2F
D1102	A-2C
D1403	A-2F
D2501	A-1D
D2502	A-1A
D2504	A-4A
F	
F0851	A-1I
FE	
FE2501	A-1A
IC	
IC0201	B-3E
IC0202	B-2F
IC0501	B-3B
IC0851	A-3G
IC0901	B-5E
IC0902	A-6G
IC0903	A-6A
IC0904	A-6H
IC0905	A-5D
IC1101	B-1C
IC1102	A-2D
IC1801	A-5A
IC2101	A-5F
IC2102	A-5D
IC2501	A-1B
IC2901	A-2B
JK	
JK2501	A-1B
JK2503	A-6A
JP	
JP0904	A-6B
JP2510	A-1B
K	
K0007	A-2A
K0013	A-2B
K0016	A-2A
K0048	A-4A
K0062	A-2C
K0068	A-4A
K0075	A-4B
K0102	A-3C
K0118	A-4C
K0158	A-5C
K0175	A-4D
K0177	A-4D
K0217	A-6A
K0236	A-6C
K0242	A-6B
K0266	A-3G
K0277	A-4F
K0282	A-4F
K0293	A-6D
K0376	A-6G
L	
L0202	A-4E
L0203	A-3E
L0204	A-4E
L0205	A-2E
L0206	A-3E
L0208	A-3G
L0209	A-3F
L0210	A-2D
L0401	A-3D
L0403	A-1F
L0501	A-3C
L0502	A-3A
L0851	A-1H
L0853	A-5H
L0854	A-4H
L1101	A-2D
L1102	A-2D
L1103	A-2C
L1105	A-2D
L1106	A-2C
L1402	A-4E
L1403	A-4F
L1406	A-3A
L1801	A-4A
L2502	A-2A
L2504	A-3A
L2902	A-2C
L2903	A-1C
LD	
LD2101	A-4D
PC	
PC0851	A-3H
PG	
PG0401	A-2B
PG0402	A-1E
PG0601	A-2E
PG0602	A-1E
PG0702	A-6E
PG0703	A-6C
PG0704	A-6I
PG0901	A-6E
PG1101	A-1D
PG2508	A-1A
PG2509	A-5A
Q	
Q0228	B-3E
Q0406	A-2F
Q0409	A-1F
Q0410	B-2F
Q0411	A-1F
Q0412	A-1F
Q0413	A-1F
Q0701	A-6H
Q0702	A-6H
Q0851	A-3H
Q0852	A-3H
Q0853	A-5H
Q0854	A-5H
Q0855	B-6G
Q0858	A-5H
Q0859	A-6H
Q0864	A-5H
Q0901	A-6A
Q0902	A-5A
Q0905	B-6D
Q0906	B-6D
Q0912	B-5F
Q0913	B-5F
Q0914	B-6H
Q1101	B-2C
Q1102	B-2C
Q1401	B-4F
Q1404	B-4D
Q1407	B-1A
Q1409	B-4D
Q1410	B-4D
Q1411	B-4F
Q1802	A-5B
Q2101	A-4G
Q2102	A-4B
Q2103	B-5F
Q2104	B-5D
Q2501	B-1C
Q2502	B-1B
Q2503	B-1B
Q2504	B-3A
Q2505	B-3A
Q2506	B-1A
Q2509	A-1B
Q2901	B-2C
QF	
QF0851	A-5H
QF0852	A-5H
R	
R0205	B-2C
R0206	B-3F
R0207	B-2C
R0208	B-2C
R0212	A-3E
R0213	A-3E
R0215	A-4D
R0216	A-4E
R0217	A-3D
R0218	A-4E
R0226	B-3D
R0227	B-3D
R0228	B-2E
R0229	A-2E
R0240	A-3F
R0241	A-3E
R0253	A-3F
R0257	A-2F
R0258	A-2D
R0263	A-3E
R0402	A-3D
R0403	B-3D
R0404	B-3D
R0407	B-3D
R0408	A-3D
R0409	B-3D
R0410	B-3D
R0420	B-1F
R0421	B-2F
R0422	B-1F
R0423	A-2F
R0424	B-3D
R0426	A-3D
R0427	A-3C
R0429	A-1F
R0430	A-1F
R0431	A-1F
R0432	A-1F
R0434	A-1F
R0437	B-3D
R0501	A-3A
R0502	A-3B
R0503	A-3A
R0504	A-3B
R0505	A-3A
R0506	A-3B
R0509	A-3B
R0510	B-3B
R0511	B-3B
R0516	A-4B
R0517	B-3B
R0520	A-4B
R0521	A-4B
R0522	B-3C
R0523	B-4C
R0524	A-4C
R0525	A-4C
R0526	B-3B
R0527	B-3B
R0530	B-4B
R0531	B-4B
R0532	B-3B
R0533	B-3B
R0534	B-3B
R0540	A-5B
R0541	A-5B
R0602	A-1E
R0605	A-1E
R0615	A-1E
R0621	A-5B
R0622	A-5D
R0623	B-5E
R0624	B-5E
R0625	A-5C
R0626	A-4E
R0627	A-5D
R0628	B-5D
R0629	B-5E
R0630	B-5E
R0631	B-5D
R0632	B-5D
R0633	B-5D
R0634	A-4C
R0635	A-4C
R0636	A-4C
R0638	A-4F
R0696	A-4F
R0704	A-6E
R0705	A-6H
R0706	A-6H
R0707	A-6H
R0708	A-6H

IDENTIFICATION OF PARTS LOCATION

MAS [MAIN] 2/2

Symbol No.	Parts Location
R0709	B-6H
R0710	A-7H
R0711	A-6G
R0712	A-6H
R0714	A-6H
R0715	A-6G
R0716	A-6F
R0851	A-1G
R0853	A-2H
R0856	A-3H
R0857	A-3H
R0859	A-2H
R0860	A-3H
R0861	A-3I
R0862	A-3H
R0863	A-3H
R0864	A-3H
R0865	A-3H
R0866	A-3G
R0867	A-3G
R0868	A-4H
R0869	B-3G
R0871	B-3G
R0872	A-5H
R0873	A-5H
R0874	A-5G
R0875	A-6G
R0878	B-5H
R0879	A-5H
R0880	A-2H
R0885	A-5H
R0886	A-5H
R0887	A-5H
R0889	A-3H
R0891	A-6G
R0892	B-6H
R0893	A-6G
R0894	A-6H
R0901	A-5D
R0902	A-5C
R0903	A-5C
R0905	A-6C
R0906	B-6E
R0907	A-6D
R0908	A-6D
R0909	A-6E
R0910	A-6D
R0911	A-6C
R0913	A-6C
R0914	A-6D
R0915	A-6D
R0916	B-6E
R0917	B-6E
R0918	A-5C
R0919	A-6B
R0920	A-6E
R0923	A-5A
R0924	B-6E
R0925	B-6E
R0926	B-6E
R0927	A-5G
R0928	B-6F
R0929	B-6F
R0934	A-6G
R0935	A-6A
R0936	A-5A
R0937	A-5A
R0939	B-5E
R0940	B-5E
R0941	A-7B
R0943	A-5F
R0944	A-5F
R0945	A-5G
R0946	A-4G
R0947	A-5F
R0948	A-6G
R0950	A-5G
R0951	A-5G
R0952	A-5G
R0954	A-5G
R0955	B-4F
R0956	A-3G
R0957	B-4F
R0963	A-4F
R0967	A-1E
R0970	A-4F
R0971	B-4F
R0972	B-4D
R0976	A-6H
R0977	A-5G
R0978	B-5E
R0979	A-6D
R0980	A-6D
R0981	A-6D
R0987	A-6E
R0988	B-5F
R0990	A-4F
R0991	B-6F
R0992	B-6F
R0998	B-5F
R0999	A-5E
R1101	B-2D
R1103	B-2D
R1104	B-1D
R1107	B-1C
R1108	B-1C
R1109	B-2C
R1110	B-2C
R1112	B-2C
R1113	B-2C
R1115	B-2C
R1116	B-2C
R1117	A-2C
R1118	B-2C
R1120	B-2D
R1211	A-2F
R1403	A-4G
R1405	B-4F
R1406	B-4F
R1407	B-4F
R1409	B-4E
R1410	B-4D
R1412	A-4D
R1413	B-2F
R1416	A-4D
R1418	A-4D
R1421	A-1A
R1422	A-2A
R1423	B-2A
R1424	A-2A
R1430	A-4D
R1433	B-4F
R1434	B-4E
R1438	B-4F
R1802	A-4A
R1806	A-5A
R1807	A-5B
R1808	A-5A
R1809	A-5A
R1818	A-4B
R1820	A-5B
R1822	A-4B
R2101	A-5G
R2102	A-6C
R2103	B-5D
R2104	A-5F
R2105	A-5F
R2106	B-4D
R2107	A-5C
R2108	A-5C
R2109	A-5C
R2110	A-5C
R2111	A-5C
R2112	A-5C
R2113	B-4D
R2114	B-5D
R2115	B-5D
R2116	A-5F
R2117	A-5G
R2501	A-1C
R2502	B-1B
R2503	A-1A
R2504	A-1B
R2507	B-1C
R2508	B-1C
R2509	B-1B
R2510	B-1B
R2511	B-1B
R2512	B-1A
R2514	A-2A
R2515	B-3A
R2517	B-3A
R2518	B-3A
R2523	B-3A
R2524	B-3A
R2527	A-1B
R2530	A-6A
R2533	B-3A
R2534	B-3A
R2542	A-4B
R2901	A-2B
R2902	A-2C
R2903	B-2C
R2904	B-2B
R2905	A-2B
R2906	A-2B
R2907	B-2B
R2908	A-2B
R2909	B-2B
RF	
RF0861	A-4H
RT	
RT1801	A-4A
S	
S0701	A-6H
S0702	A-6I
S0703	A-6H
S0704	A-6G
S0705	A-6H
S0706	A-6G
S0707	A-6F
S0708	A-6G
S2101	A-5C
S2102	A-4G
S2103	A-6C
T	
T0401	A-1F
T0851	A-4H
X	
X0201	A-4E
X0901	A-5F
X0902	A-4F
X2901	A-2B
ZD	
ZD0851	A-3H
ZD0861	A-4H
ZD0862	A-5I
ZD0864	A-5H
ZD0901	A-6H
ZD0903	A-4F
ZD0904	A-6H
ZD2501	A-2A
ZD2502	A-3A

MAIN [MAS] – SIDE B – DIFFERENCE TABLE

NOTE: This table listes the different components marked with asterisks (*) in the circuit board diagrams.

SYMBOL-No.	FX621A	FX623A
C2901	×	○
C2903	×	○
C2905	×	○
C2909	×	○
C2910	×	○
Q2901	×	○
R2903	×	○
R2904	×	○
R2907	×	○
R2909	×	○

MAS CIRCUIT BOARD[SIDE B]



MAS(MAIN)-SIDE B-
[PATTERN No.JA1376-3]

CHAPTER 7 TROUBLE DISPLAY, BLOCK DIAGRAMS AND MICROPROCESSOR PIN FUNCTION TABLES

1. Trouble Display Function

This VCR has a function which displays mechanism malfunctions, etc. in the LCD display. Use this function to analyze the cause when the power is shut off due to a malfunction, etc. in the mechanism.
Two types of information are displayed, ① The operation mode when the malfunction has occurred, ② Malfunction Code No.

Procedure to display a malfunction

Press the "CHANNEL ▼" button on the VCR when the power is turned off and hold it; the malfunction code number is displayed while the button is held depressed.

Procedure to clear the malfuntion display

Press the "PLAY" button on the VCR and hold it, then press the microprocessor "RESET" button to initialize the trouble display.

The details of the malfunction are displayed as follows.

LCD DISPLAY



【Display of Details of Malfunction】

Displayed No.	Item	Details
"00"	No malfunction	
"01"	FL mechanism lock	Malfunction in insertion/ejection of cassette
"02"	Capstan lock	Malfunction of capstan motor drive during tape unloading
"04"	Reel lock	Reel rotation trouble when tape is running
"05"	Cylinder lock	Cylinder rotation malfunction
"07"	Loading mechanism lock	Malfunction in shifting mechanism mode
"16"	Servo lock	Shorting of 5V detected

【Mode Display When Malfunction Has Occurred】

Mode	Display	Mode	Display
Stop	No display	Forward search	SRCH
Fast forward	FF	Reverse search	-SRCH
Rewind	REW	Slow motion play	SLOW
Recording	REC	Reverse motion slow play	-SLOW
Recording pause	REC (flashes)		
Playback	PLAY	Still motion play	STILL
Reverse playback	-PLAY		

No symbols are displayed if the malfunction occurred when a cassette was inserted or ejected, or the power was switched on from off, and off from on.

Troubleshooting According to Malfunction Display

If "01" Appears in the Display



If "02" Appears in the Display



If "04" Appears in the Display



Note: The cylinder system has priority. If the cylinder motor is not driven normally, the capstan motor will not be driven.

If "05" Appears in the Display



If "07" Appears in the Display




If "16" Appears in the Display
Is 5V present at IC901-41 during power ON ?
YES
IC901 faulty
NO
Is 5V output at IC905-1 ?
YES
Pattern between IC905-1 and IC901-41 faulty
NO
Is 9V input to IC905-3 ?
NO
IC905 faulty
YES
Check the peripheral circuits of Q858 and Q853 in the regulator block.

2. BLOCK DIAGRAMS
SYSTEM CONTROL



SERVO


CYL. MOTOR DRIVE
MOTOR DRIVE
MATRIX
TACH SENSOR
W
V
U
CYL. FG
12V
CYL. SERVO
TACH PULSE
PG602
To LOADING MOTOR
D909 D908
A13.5V
CYLINDER MOTOR
IC901
SERVO CONTROL
(MAIN μP)
CYL. SPEED CONTROL
CAPST. SPEED CONTROL
SIGNAL GEN
AUD. 30Hz
C. FG DIVIDER
SW30Hz
SW30Hz GEN
CYL. PHASE CONTROL
CAPST. PHASE CONTROL
TRACKING M. M
REF30 GEN
V. SYNC SEPA
C. SYNC
CTL DIVIDER
PB CTL AMP
REC CTL AMP
MODE OUTPUT
FF/REV
To VIDEO/ AUDIO CIRCUIT
SO
SI
PG601
PG001
C. FG
Q912. Q913.
Q864. ZD864
V. CAPST GEN
CAPST. CONT.
V. CAPST
CAPST. SERVO
REVERSE
PG402
CONTROL HEAD
IC001
CAPSTAN MOTOR DRIVE
FG AMP
C. FG SENSOR
MR001
MOTOR DRIVE
ROTOR POSITION SENSOR AMP
H001
H002
H003
CAPSTAN MOTOR
MAIN CONTROL [MAS]

AUDIO



1 2 3 4 5 6 7 8

AUDIO 7-12 7-13 AUDIO

VIDEO


(FOR FX623A)
JK2503
VIDEO INPUT 2
IC2501
VIDEO INPUT SW
JK2501
VIDEO INPUT 1
(FOR FX621A)
VIDEO OUTPUT 1
FE2501
RF/TUNER UNIT
VIDEO (TU)
VIDEO (RF)
Q1407
IC901
OSD
IC2901
AUTO CLOCK
(FOR FX623A)
IC201
VIDEO PROCESS
LINE
TU
AGC
SW7
REC
PB
Y-LPF FILTER
SW4
CLAMP
YNR
SW9
SUB DE-EMPH
SUB EMPH
MAIN EMPH
FM MOD.
EE
SW6
PICTURE CONT.
NOISE CANCEL
FEED BACK CLAMP
ALC
SQUELCH
MAIN DE-EMPH
SUB LPF
FM DEMOD.
LIMIT
PHASE EQ
FM AGC
629KHz TRAP
SW10
IC202 (1/2)
Y-CCD DELAY
1H DELAY
SW11
SW13
BPF
SW15
MAIN CONV. 2
MAIN CONV. 1
1.3MHz LPF
SW12
150ns DELAY
SW17
VCA
ACC
COLOR KILLER
SW14
LUMA TRAP
AUDIO TRAP
2.2MHz LPF
IC202 (2/2)
C-CDD DELAY
BURST EMPH
COLOR KILLER
2MHz LPF
IC1101
VIDEO HEAD AMP
REC AGC
PB AMP
Q1101
S10
S15
S9
SP
EP
PG1101 CN0001
SP CH-2
SP CH-1
EP CH-2
EP CH-1
LUMA/CHROMA [MAS]

POWER SUPPLY



3. MICROPROCESSOR PIN FUNCTION TABLES

LCD DRIVER μP (IC1701)

Pin No.	I/O	Active Level	Abbreviation	Function
1	–	–	SEGMENT (1)	Not used.
2	–	–	SEGMENT (2)	
|	|	|	|	
5	–	–	SEGMENT (5)	
6	O	Pulse	SEGMENT (6)	LCD segment control outputs.
7	O	Pulse	SEGMENT (7)	
|	|	|	|	
31	O	Pulse	SEGMENT (31)	
32	O	Pulse	SEGMENT (32)	
33	O	Pulse	COM1	LCD common (COM) control outputs.
34	O	Pulse	COM2	
35	O	Pulse	COM3	
36	I	Lo	RESET (L)	Initializes the LCD-μP when power is supplied.
37	I	Hi	VDD	A5V power input.
38	I	–	VDD 1	LCD drive bias.
39	I	–	VDD 2	LCD drive bias.
40	–	Lo	VSS	Ground.
41	I/O	–	OSC	Generates a 32kHz signal for key scanning.
42	I	Lo	LCD LOAD	LOAD signal between the LCD-μP and M-μP. "Lo" input enables chip select.
43	I	Pulse	CLOCK (M-LCD)	The data is transferred from the M-μP, synchronized with the clock signal.
44	I	Pulse	DATA (M-LCD)	

MAIN μP (IC901)

Pin No.	I/O	Active Level	Abbreviation	Function
1	O	Hi	BACKLIGHT	LCD backlight switching signal.
2	–	–	GND	Ground.
3	I	A/D	SHUTTLE 2	Not used.
4	I	A/D	SHUTTLE 1	
5	I	A/D	KEY IN	Key matrix input.
6	I	A/D	FL/TAB	Cassette position/erase prevention tab detection input. Hi: TAB SW OFF (with tab), Mid: TAB SW ON (without tab), Lo: When cassette is being inserted/ejected. When a cassette without its erase prevention tab is inserted, recording is inhibited, and when the timer is programmed, it is ejected automatically.
7	I	Lo	POWER STOP	When A5V voltage drops and "Lo" is input, the M-μP detects that a power failure has occurred.
8	I	Hi	S-CURVE	Detects the AFT (S-CURVE) signal from the IF unit to fine tune to a station.
9	I	A/D	M. STATE 3/4	The signals which detect the mechanism state are input to control the loading motor.
10	I	A/D	M. STATE 1/2	

Pin	EJECT	UNLOAD	REV.	R.SLOW	SLOW	R/P	STOP2	FF/REW
9	0	2.5	1.8	2.5	3.05	3.05	2.5	0
10	1.8	3.05	0	0	0	1.8	2.5	3.05

11	I	A/D	ENV. (VIDEO)	Audio and video envelope level inputs for autotracking.
12	I	A/D	ENV. (AUDIO)	
13	I	A/D	MODEL SW	Model switching control.
14	I	Hi/Mid/Lo	MPX MODE	Lo: Stereo signal input, Mid: Bilingual signal input, Hi: Mono signal input.
15	I	–	A5V	Connected to A5V.
16	I	Lo	RESET (L)	Initializes the M-uP when power is supplied.
17	O	Hi	MONO OUT	Output to control the MTS decoder output mode to mono.
18	O	Hi	TUNER LOAD	Not used.
19	O	Lo/Hi	L1 (L) / L2	L1 / L2 switching control signal output.
20	O	Lo/Hi	CONV. CH3/CH4	CH-3/CH-4 switching control signal output.
21	O	Hi/Lo	TV (L) / VCR	RF converter (VCR/TV switching) control signal output.
22	I	–	B5V	Connected to B5V.
23	O	Pulse	SW30Hz-A	Head switching pulse output for audio circuits.
24	O	Pulse	SW30Hz	Head switching pulse output.
25	O	PWM	CAPST. PWM	Cylinder and capstan motor servo control outputs.
26	O	PWM	CYL. PWM	
27	O	Hi	V.PULSE	Artificial V sync signal for trick play.
28	O	Pulse	C. ROTARY	Chroma rotation control signal.
29	O	Hi/Lo	H. AMP SW	SP/EP head switching control signal (pulse during trick play).
30	I	Hi/Lo	COMP	SP/EP head switching control signal (pulse during trick play).
31	I/O	Pulse	CTL (+)	CTL signal input/output.
32	I/O	Pulse	CTL (–)	
33	–	–	GND	Ground.
34	I	Pulse	CTL AMP 1	CTL amp inputs.
35	I	Pulse	CTL AMP 2	
36	I	Pulse	CTL AMP 3	
37	O	Pulse	CTL AMP (O)	CTL amp output.
38	I	Pulse	CYL.FG	Cylinder FG (CYL.FG) pulse input. Controls the cylinder speed during recording and playback.
39	I	Pulse	TACH PULSE	Tach pulse input. Comparison (feedback) signal which controls the recording cylinder phase.
40	I	Pulse	CAPST.FG	Capstan FG (CAPST.FG) pulse input. Used to control the capstan motor.
41	I	–	5V	Connected to 5V.
42	I	–	5V	Connected to 5V.
43	I	–	C.VIDEO	Video signal input.

Pin No.	I/O	Active Level	Abbreviation	Function
44	O	–	V.REF	Reference bias/clamp bias voltage.
45	O	–	C.VIDEO OUT	Video signal output.
46	–	–	CHARA. BIAS	Not used.
47	–	–	AFC LPF	An LPF is attached externally for AFC.
48	–	–	AFC OSC	Oscillator for AFC.
49	–	–	GND	Ground.
50	I	Pulse	DOSC IN	OSD dot clock oscillator.
51	O	Pulse	DOSC OUT	
52	O	–	2fsc (7.16MHz)	These generate a 7.16MHz signal as the clock signal for the OSD and servo circuits.
53	I	–	2fsc (7.16MHz)	
54	I	Pulse	C.SYNC	Composite sync signal input. Controls the cylinder speed during recording.
55	O	Hi	BLUE BACK	Blue background control signal output.
56	O	Hi	HIFI MUTE	Hi-Fi audio muting control output during recording.
57	O	Pulse	DATA (M-YC/LA)	Common communication lines with VIDEO/LINEAR AUD. ICs; data is transferred, synchronized with the clock signal.
58	O	Pulse	CLOCK (M-YC/LA)	
59	O	Lo	PB (L)	Sets the video/audio circuits to the playback mode.
60	O	Hi	REVERSE	Sets the drive direction of the capstan motor to reverse.
61	O	Hi	REC (AUDIO)	Sets the audio circuit to the recording mode.
62	O	Pulse	CTL RESET	Not used.
63	I	Lo	COPY GUARD	Not used.
64	O	Pulse	IR OUT	Signal output to the cable box control circuit.
65	O	Hi	UNLOAD	Loading motor drive signals which set the mechanism to the commanded mode.
66	O	Hi	LOAD	
67	O	Hi	LM CONT.	Flying erase control (not used)/signal to control the voltage applied to the loading motor when forward slow is switched to reverse slow and vice versa.
68	–	–	TEST	Ground.
69	I	–	X2 (32kHz)	These generate a 32.768kHz signal as the clock signal for the VCR's clock.
70	O	–	X1 (32kHz)	
71	–	–	GND	Ground.
72	I	–	OSC 1 (10MHz)	These generate a 10MHz signal as the system clock signal in modes other than back-up.
73	O	–	OSC 2 (10MHz)	
74	O	Hi	LINE MUTE	Audio output muting control.
75	O	Hi/Lo	CAPST. Q.R	Cylinder and capstan motor phase control outputs.
76	O	Hi/Lo	CYL. Q.R	
77	O	Hi	POWER CONT	Power on/off control. When the power switch is operated, a cassette is inserted or a power failure is detected, the internal power supply is switched to be on/off.
78	O	Lo	SP (L)	Tape speed output.
79	I	Hi	V. REC MUTE	Video signal record muting control. Prevents the signal from being supplied to the video heads.
80	O	Lo	EDS CE	LOAD signal between the M-μP and AUTO CLOCK IC.
81	O	Hi	MPX MUTE	Tuner audio muting control.
82	I	Pulse	IR PULSE	Receives the remote control code from the infrared receiver and sets the VCR to the specified mode. AV BUS data input.
83	O	Hi/Lo	V. CAPST. CONT. 1	These are output in the slow, still, playback, recording, fast forward and rewind modes to control the voltage applied to the capstan motor.
94	O	Hi/Lo	V. CAPST. CONT. 2	
84	O	Hi	REC	Sets the video and audio head amp circuits to the recording mode.
85	I	Pulse	LINE 21	EDS LINE 21H pulse input.

(83) V.CAPST. CONT 1	(94) V.CAPST. CONT 2	V.CAPST
Hi	Hi	7.5 V
Lo	Hi	9.5 V
Lo	Lo	13.5 V

Pin No.	I/O	Active Level	Abbreviation	Function
86	I	Lo	REW END (L)	When "Lo" is input from the mechanism sensor, the current mode is released. Two sensors detect the two ends of tape. When "Lo" is input from both sensors, the M-μP detects that a cassette is not loaded in the VCR.
87	I	Lo	FWD END (L)	
88	I	Pulse	T.REEL	Calculates the period of the take-up reel pulse to detect whether or not slack tape is taken up on the reel. If slack tape is not taken up, the M-μP stops the mechanism. The supply reel pulses are used with the take-up reel pulses to calculate the tape remaining time.
89	I	Pulse	S.REEL	
90	I	Lo	CHECK	Checks short-circuits in the 5V/9V power supplies. (This pin goes "Lo" normally when power is off.)
91	O	Hi	ST/SAP OUT	Output to control the MTS decoder so it is set to the SAP mode.
92	I/O	Pulse	DATA (M–ROM/HA/TUN)	Common communication lines with the ROM/Hi-Fi AUD./TUNER; data is communicated, synchronized with the clock signal.
93	O	Pulse	CLOCK (M–ROM/HA/TUN)	
95	O	Pulse	CLOCK (M–EDS)	Communication lines with the Auto clock set IC; data is transferred, synchronized with the clock signal.
97	O	Pulse	DATA (M–EDS)	
96	I	Pulse	DATA (EDS–M)	EDS caption data input.
98	O	Pulse	CLOCK (M–LCD)	Communication lines with the LCD DRIVER; data is transferred, synchronized with the clock signal.
100	O	Pulse	DATA (M–LCD)	
99	O	Hi	LCD LOAD	LOAD signal between the M-μP and LCD-DRIVER.

4. Troubleshooting the Switching Regulator

This section summarizes the troubleshooting of defects in the switching regulator. Perform diagnosis, taking each defective phenomenon into consideration. Even if the same defective phenomenon appears, it may be caused by other circuits, not by the switching regulator, so use this item as a reference.

Cautions when checking and repairing the switching regulator circuit

When using test equipment to check the primary circuit (circuit No. 8XX) of the power supply, use a two-pole AC outlet for the test equipment. If a three-pole AC outlet (which is connected to ground) is used, the circuits could be broken. (Attach a conversion adapter to the test equipment plug to connect it to a three-pole outlet).

Be careful of electric shock

A heat sink which generates a high voltage is provided with Q851 in the switching regulator block. "HIGH VOLTAGE" is printed on the heat sink. Take great care of this section when servicing or handling the VCR when it is turned on.
(Supplement: The heat sinks of Q853 and Q864 do not generate a high voltage.)

Method to judge that the switching regulator is faulty


Are the power supply of the secondary circuit and ground shorted?
YES
Correct the short-circuit.
NO
Does the constant-voltage feedback control (PC851 peripheral circuit) operate?
YES
Is an AC rectified voltage (approx. 130V) applied to terminal (3) of the transformer?
NO
Has F851 blown?
YES
Replace F851, Q851, Q852, D851 and R856.
NO
Are there any missing parts in the photo-coupler's peripheral circuits (PC851 and Q852) or any mistakes in alues?
YES
NO
Replace Q851, Q852, PC851 and IC851. Does the switching regulator operate?
NO
Switching regulator faulty

Troubleshooting by Observing Defective Phenomena

If the switching regulator is normal and there is a defect in another circuit (shorting between the power supply and ground of the secondary circuit), the protector circuit operates and the power is not turned on. If a defect occurs in the switching regulator, a phenomenon such that the VCR power is not turned on or the power fuse has blown also occurs.


1. Power is not turned on
Are the power supply of the secondary circuit and ground shorted?
YES
Correct the short-circuit.
NO
Are any parts of the constant-voltage feedback citcuits (PC851, Q852, and IC851 peripheral circuits) installed incorrectly or some values mistaken?
YES
Install the correct parts.
NO
Is an AC rectified voltage (approx. 130V at D851's anode) applied to terminal (1) of the transformer?
YES
L851, D851 or/and C851 faulty
(especially, it is highly possible that L851 and D851 are faulty.)
NO
Is the resistance of R856 incorrect when measured by a tester?
YES
R856 faulty
NO
Is 5.4V present at the 5V line (positive terminal of C873) of the secondary output ?
YES
Has the IC protector (QF851) blown ?
NO
Circuits other than power supply faulty
YES
Replace the IC protector
NO
Is the oscillation waveform at the 5V terminal of the secondary transformer output normal ?
NO
T851 faulty
YES
IC851 or D858 faulty
T851-8
5.6V
0
100kHz~120kHz



4. Cylinder motor does not turn


Is the card connector between the MAS and cylinder motor boards inserted securely ?
NO
Insert it securely. Is the card connector the right way up ?
NO
The printed surface of the card connector should be up with respect to the connector on the cylinder motor board when it is inserted.
YES
YES
Is the card connector disconnected ?
YES
Replace the card connector ?
NO
Is there dirt on the cylinder ?
YES
Clean the cylinder.
NO
Are 12V and 5V output at PG602-4 and 1 ?
NO
Check the switching regulator.
YES
Is CYL.SERVO input to PG602-7 ?
NO
Is CYL.PWM output from IC901-26 ?
NO
IC901 faulty
YES
YES
Check the line between IC901-26 and PG602-7.
Cylinder motor faulty

5. Loading motor does not turn



VT-FX621A/FX623A

HITACHI

VT-FX621A
VT-FX623A

TK No. 4624E Image & Information Media Systems Division, Tokai

Copyright © Hitachi, Ltd. 1996. All rights reserved. Printed in Japan (III)

VT-FX621A/FX623A